


EUT INTERNAL PHOTOS


EUT UNCOVER VIEW 1



EUT UNCOVER VIEW 2




EUT UNCOVER VIEW 3




ANTENNA


PIFA Antenna




MAIN BOARD TOP VIEW




MAIN BOARD TOP VIEW (WITHOUT SHIELDING)




MAIN BOARD REAR VIEW




RF MODULE TOP VIEW-RTL8852CE (WITH SHIELDING)



RF MODULE REAR VIEW -RTL8852CE




RF MODULE TOP VIEW-RTL8852CE (WITHOUT SHIELDING)




RF MODULE TOP VIEW-MT7922A22M(WITH SHIELDING)



RF MODULE REAR VIEW-MT7922A22M



RF MODULE TOP VIEW-MT7922A22M (WITHOUT THE SHIELDING)



Battery-L22C4PA1



Battery-L22M4PA1



Battery-L22D4PA1



Battery Photo (REAR)

