

Test positions for Head:



Figure 1 Left Touch mode




Figure 2 Left Tilt 15° mode




Figure 3 Right Touch mode



Figure 4 Right Tilt 15° mode

Test positions for body:

According to the antenna position, the Body SAR is tested at the following 6 test positions all with the distance =5mm between the EUT and the phantom bottom:



Test positions for Limb:

According to the antenna position, the Limb SAR is tested at the following 6 test positions all with the distance =0mm between the EUT and the phantom bottom:



Figure 11 Front Side mode



Figure 12 Back Side mode



Figure 13 Back Tilt Side mode



Figure 14 Left Side mode



Figure 15 Right Side mode




Figure 16 Top Side mode