

KWG100–User Manual

FCC Warning

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions;

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

RF Radiation Exposure Statement

This equipment complies with FCC RF Radiation Exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

1.Fundamental Components


- Main
- Handset
- Ant.
- Battery
- TA
- User Manual

2.How to Assemble.


- Open the battery cover (Bottom Side)
- Pull left SIM card socket cover
- Open the SIM card socket cover
- Insert the SIM card into the SIM card socket cover
- Close the SIM card socket cover
- Pull right SIM card socket cover
- Connect the battery into the Battery Connector(3Pins)
- Connect handset code into the RJ11 Socket
- Close the battery cover
- Connect the ANT
- Connect the TA
- Turn on the Power Switch

3. Name and Function of each Part


a. Main-Top




b. Main-Back



c. Main-Bottom



d. Handset



4.Explanation of Icon

-  : Strength of RSSI.
-  : Quantity of Battery remaining
-  : Entering of Menu state
-  : Alarm is set
-  : There are data in Phonebook
-  : There are Unclosed Messages.
-  : Call is Connected

5.Key Discription



- MENU : Menu Hot Key
- CLEAR : Clear Hot Key
- STORE : Store Hot Key
- MESSAGE : Message Hot Key
- REDIAL : Redial Hot Key

- VOLUME : Volume Hot Key
- SPEAKER Hot Key
- 0 ~ 9 : Number Key
- < > : Navigation Key
- 2 ~ 9 : Alphabet Key

6.How to make a call

- a. Off Hook -> Press call number -> Call connected -> Conversation
- b. Press call number -> Call connected -> Conversation (**Speaker Phone**)

7.How to receive a incoming call

- a. Incoming Ring -> Off Hook
- b. Incoming Ring -> Press SPK Key (**Speaker Phone**)

8.How to end call.

- a. Conversation -> On Hook
- b. Conversation (Speaker Phone) -> Press SPK Key

9.Function

a. Call History

1:Daided No.	1:Display 2:Store In SIM 3:Store In Phone 4:Delete
2:Received No.	1:Display 2:Store In SIM 3:Store In Phone 4:Delete
3:Missed No.	1:Display 2:Store In SIM 3:Store In Phone 4:Delete
4:Delete ALL	Are You Sure?

b. Phonebook

1:Name Search	1:Edit
	2:Send Message
	3:Display
	4:Copy to phone
	5:Delete
2:Number Search	1:Edit
	2:Send Message
	3:Display
	4:Copy to phone
	5:Delete
3:Add Entry	1:Phone
	2:SIM
4:Speed Dials	1:Voice Mail
	2:Empty
	...
	9:Empty
5:SDN	Empty List
6:Memory Status	Phone 1/250 SIM 2/250
7:Delete ALL	1:Phone
	2:SIM
8:Memory In Use	1:Phone
	2:SIM

c. Time Setting

1:Alarm Set	1:On
	2:Off
2:Call Duration	1:Last Incoming
	2:Last Outgoing
	3:Total Incoming
	4:Total Outgoing
	5:Reset All Calls
3:Time/Date Set	Enter Date -> Enter Time
4:Time Display	1:12 Hour Clock
	2:24 Hour Clock

d. Sound Setting

1:Ring Tone	Melody 1 Melody 2 ... Melody 8
2:Ring Volume	1:Level 1 2:Level 2 ... 5:Level 5
3:Alert Set	1:Service Alarm 2:Minute Alarm 3:Connect Alarm
4:Alarm Sound	Melody 1 Melody 2 ... Melody 8

e. Configuration

1:DTMF Length	1:Normal 2:Long
2:Language	1:English 2:Spanish 3:automatic
3:Call Divert	1:All Voice Calls 2:If Busy 3:If Not Answered 4:If Out Of Reach 5:If Not Available 6:Cancel Divert
4:Call Waiting	1:Status 2:Activate 3:Deactivate
5:Auto Hyphen	1:On 2:Off

f. Security

1:Greeting	1:Enabled
	2:Disabled
2:Call Barring	1:All Outgoing Calls
	2:International Calls
3:Clear Memory	Enter Password
4:Reset Phone	Enter Password
5:Phone Lock	1:Enable
	2:Disable
6:Change Code	Enter Lock Code
7:Own Number	1>List
	2:Add
8:PIN	1:Enable PIN
	2:Disable PIN
	3:Change PIN
9:Auto Send Time	>OFF >3 Sec >5 Sec >8 Sec