

User Manual

CAUTION: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

1. Channel UP: Pressing this button will step up to the next channel. The highest channel is 14.
2. Channel Down: Pressing this button will step down to the next channel. The lowest channel is 1.
3. 14 Selectable Channels Display: This display shows the currently selected transmit channel which is from 1 to 14.
4. 3.5mm Stereo Audio Input: A 3.5mm stereo sound source should be connected to this connector.
5. DC-6V Power Input: A 6V DC power supply should be connected to this connector.
6. Antenna Base: Adjusting this antenna will make the transmitting effect better.

Operation

1. Connect 6V DC power supply to ⑤.
2. Connect 3.5mm stereo sound source to ④.
3. Press ① or ② to select a channel. ③ will display your selected channel which is from 1 to 14.
4. Adjust ⑥ to make the transmitting effect better.