

2022 INSTRUCTION



- Channel Code : 6 code
- Remote Frequency : 315MHz
- Remote Range : 20meter
- Battery type : L1028 12V DC Alkaline

OPERATIONS:

- Open the battery cover and put one battery into
- Control of the polar as battery(+&-)
- Press On/Off button to control receiver

NOTICE:

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.