




TOPTECH PLASTICS CO. LTD

USER MANUAL

Model: K6601 "EAGLE" No: 1 battery-driven Stunt Plane complete with a remote-controller and one set of battery's re-charger.



Technical Specifications:

- 1) This product is controlled by three-channel controller
- 2) Wingspan: 720mm (28.34").
- 3) Total length: 610mm (24").
- 4) Total weight: 254g
- 5) Effective remote control distance: 200m/656 feet.
 - Flying time: 8~15 minutes.
 - Flying height: around 180m.
 - Vertical lift-off is possible.
- 6) The plane can perform 360° somersault, wave flying, and vertical climbing etc.
- 7) High-power Ni-MH rechargeable batteries are used as drive.
- 8) This product is made of eco-friendly high-strength EPP material.

ATTENTION:

- 1) Please check and ensure that all parts and fixing tools are included as stipulated in the packing list.
- 2) Before assembling the plane, please read the instruction carefully and follow the steps as shown in the manual

accordingly.

- 3) This model K6601 is recommended for adults and children above the age of 12 years.
- 4) When the propeller is rotating at a high speed, never touch it with your fingers or any other project as this may cause personal injury or damage to the plane.
- 5) Do not "fly" the plane in the vicinity with high rise buildings, high-voltage wire, trees and crowded area.
- 6) Do not dispose the used or faulty batteries into open fire as it might cause explosion.
- 7) The 8 pieces of "D" ALKALI batteries that required for the CHARGER are not included.

Please refer to the operational manual (provided) for the proper guides to enhance the performance of this toy plane. However, should you encounter any difficulty during the operation process and are unable to resolve, please contact us at web site: www.sunfong.com or e-mail: sanjiang@dgksk.net and we shall be pleased to assist you.