




Cartoon Race Car Toys
[Product Name XXXXXXXXX FR]
[Product Name XXXXXXXXX ES]
[Product Name XXXXXXXXX JP]
B09TL43BMJ

Table of Contents

1. Important Safeguards	3
2. Battery Warnings	3
3. Explanation of Symbols	3
4. Intended Use	3
5. Before First Use	3
6. Tools Needed	4
7. Product Description	4
8. Use	6
8.1 Inserting batteries	6
8.2 Switching on/off	7
8.3 Pairing the car with a controller	7
8.4 Controlling the car	7
8.5 Attaching the toy figure	7
8.6 Making sounds	7
9. Cleaning and Maintenance	7
9.1 Cleaning	7
9.2 Storage	7
10. Frequently Asked Questions	7
11. FCC – Supplier's Declaration of Conformity	8
11.1 FCC Compliance Statement	8
11.2 FCC Interference Statement	8
12. Canada IC Notice	8
13. Disposal (for Mexico only)	8
14. Battery Disposal	9
15. Specifications	9
16. Feedback and Help	9

1. Important Safeguards



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons including the following:

⚠ WARNING CHOKING HAZARD!

Not for children under 3 yrs.

⚠ WARNING

Do not play with this toy near people with electronic devices such as pacemakers. Operation of a remote control toy in close proximity to a heart pacemaker could cause interference or failure of the pacemaker.

⚠ CAUTION ELECTRIC TOY!

Not recommended for children under 3 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

- It is recommended that this product is periodically examined for potential hazards. Any potentially hazardous parts shall be repaired or replaced when needed.
- The instruction sheet must be retained since it contains important information.

SAVE THESE INSTRUCTIONS

2. Battery Warnings

NOTICE The batteries are not included.

- Non-rechargeable batteries are not to be recharged.
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity (+ and -).
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

3. Explanation of Symbols

V	Volts
— — —	Direct current (DC).

4. Intended Use

- This product is intended for children over 3 years old.
- This product is intended to be used in dry indoor areas only.


5. Before First Use

⚠ DANGER Risk of suffocation!


Keep any packaging materials away from children and pets – these materials are a potential source of danger, e.g. suffocation.


- Remove all the packing materials.
- Remove and review all components before use.
- Check the product for transport damages.

6. Tools Needed



7. Product Description






- | | |
|------------------------------------|----------------------------------|
| A Car 1 | H Controller 1 |
| B Car hood | I Forward button |
| C Car seat base | J Reverse and turn button |
| D Number plate | K Car 2 |
| E Battery compartment cover | L Controller 2 |
| F On/off switch | M Toy figures x4 |
| G On/off and sound switch | |


8. Use

8.1 Inserting batteries


NOTICE Always insert batteries correctly with regard to polarity (+ and -) marked on the battery and the product.



1. Use a screwdriver to loosen the screws on the battery compartment covers (E) of the cars (A, K) and the controllers (H, L) (Fig. 1).



2. Insert 2 x 1.5 V AA batteries (not included into each battery compartment of the controllers (H, L) (Fig. 2).



3. Insert 3 x 1.5 V AA batteries (not included) into each battery compartment of the cars (A, K) (Fig. 3).
4. Refit the battery compartment covers (E) and tighten the screws.

8.2 Switching on/off

8.2.1 Car

- ▶ To switch on with sound, set the on/off and sound switch (G) to the  icon.
- ▶ To switch on without sound, set the on/off and sound switch (G) to the  icon.
- ▶ To switch off, set the on/off and sound switch (G) to the **O** position.

8.2.2 Controller

- ▶ To switch on, set the on/off switch (F) to the **I** position. The controller (H/L) automatically pairs with the car (A/K), the headlights on the car flashes twice.
- ▶ To switch off, set the on/off switch (F) to the **O** position.

8.3 Pairing the car with a controller

NOTICE

- ▶ Pair only 1 car and 1 controller at a time.
- ▶ Cars can be paired with the either colored remote.
- ▶ When a car or a controller was turned off after successful pairing, a re-pairing is needed to continue to operate the car with the controller. Follow the pairing steps again to re-pair.

1. Set both the car (A/K) and the controller (H/L) to off.
2. Switch on the car (A/K).
3. Switch on the controller (H/L). The controller (H/L) automatically pairs with the car (A/K). Pairing is successful when the headlights on the car (A/K) flashes twice.

8.4 Controlling the car

- ▶ Press the forward button (I) to go forward.
- ▶ Press the reverse and turn button (J) to reverse and turn.

8.5 Attaching the toy figure

Insert the desired toy figure (M) onto the car seat base (C).

8.6 Making sounds

The cars (A,K) has buttons that play sounds. Press on the car hood (B), car seat base (C) or the number plate (D) to play a sound.

9. Cleaning and Maintenance

NOTICE

- ▶ Take out the batteries in the product before cleaning.
- ▶ During cleaning do not immerse the electrical parts of the product in water or other liquids. Never hold the product under running water.

9.1 Cleaning

- ▶ To clean the product, wipe with a soft, slightly damp cloth.
- ▶ Wipe the product dry after cleaning.
- ▶ Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.

9.2 Storage

- ▶ Store the product in its original packaging in a dry area. Keep away from children and pets.

10. Frequently Asked Questions

Problem	Solution
The car/controller does not switch on.	▶ Check if the car/controller is out of battery.
The car is not pairing with the controller	▶ Switch off both car and controller and try to pair again.

11. FCC – Supplier's Declaration of Conformity

Unique Identifier	B09TL43BMJ - Amazon Basics Cartoon Race Car Toys - 2 Pack
Responsible Party	Amazon.com Services LLC.
U.S. Contact Information	410 Terry Ave N. Seattle, WA 98109 USA
Telephone Number	(206) 266-1000

11.1 FCC Compliance Statement

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - this device may not cause harmful interference, and
 - this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

11.2 FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

12. Canada IC Notice

- This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
 - this device may not cause interference, and
 - this device must accept any interference, including interference that may cause undesired operation of the device.
- This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.
- This Class B digital apparatus complies with Canadian CAN ICES-003(B) / NMB-003(B) standard.

13. Disposal (for Mexico only)

The General Law for Prevention and Integral Management of Wastes (LGPGIR) aims to minimise the impact of electrical and electronic goods on the environment, by increasing re-use and recycling and by reducing the amount of electrical waste going to landfill. This product must be disposed separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centers in order to conserve natural resources. For information about your recycling drop off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your household waste disposal service.

Importer address:
 Amazon México, S. de R.L. de C.V.
 Juan Salvador Agraz No.73 Piso 5 Colonia Santa Fe Cuajimalpa Delegación Cuajimalpa De Morelos Cuidad de México, Distrito Federal C.P. 05348

14. Battery Disposal



Do not dispose of used batteries with your household waste. Take them to an appropriate disposal/collection site.



To learn more about recycling batteries, visit:
call2recycle.org/what-can-i-recycle


15. Specifications

Voltage/battery type	Car: 4.5 V  3x 1.5 V AA Controller: 3 V  2x 1.5 V AA
Net weight	Car: approx. XX oz (XX g) Controller: approx. XX oz (XX g) Toy figures: approx. XX oz (XX g)
Dimensions (W x H x D)	Car: approx. 5.6 x 3.9 x 3.1" (14.2 x 10 x 8 cm) Controller: approx. 4.3 x 1.2 x 3" (11 x 3 x 7.5 cm) Toy figures: approx. 1.8 x 2 x 3.5" (4.5 x 5 x 9 cm)
Materials	Plastic XX Plastic XX Plastic XX
Car (A) operating frequency	XX MHz
Car (K) operating frequency	XX MHz

16. Feedback and Help

We would love to hear your feedback. To ensure we are providing the best customer experience possible, please consider writing a customer review.

Scan QR Code below with your phone camera or QR reader:



If you need help with your Amazon Basics product, please use the website or number below.



amazon.com/gp/help/customer/contact-us



+1 877-485-0385



amazon.com/AmazonBasics

MADE IN CHINA
FABRIQUÉ EN CHINE
HECHO EN CHINA
中国製

V01-05/22