



1 INTERNAL PHOTOS OF TESTED EUT (RFID LOCATION)

1.1 Location of RFID Antenna for all equipments




Location of RFID antenna, front face



Location of the RFID antenna, rear face with cover removed.

The connection between antenna and RFID board is a straight connector 8 pins with an 8 wires cable unshielded.



Note – the 13.56MHz is generated on the RFID antenna board

1.2 Location of the RFID board P066C

