





9.6V A size 2100mAh  
Rechargeable Battery  
Pack





## The RC Dolphin Surfer Pack



RC Dolphin Surfer with 4 fins

AC Adapter  
(60Hz 300mah  
AC input: 230V  
DC output: 9V)



Antenna

Radio Controller

## Operating Instructions

Please read through this instruction manual carefully before starting to operate.

It is recommended to operate the RC Dolphin Surfer under adult supervision. Do not allow young children to play in or around water without adult supervision.

RC Dolphin Surfer is not recommended for children under 10 years of age.


Please keep this instruction manual for future reference

## Features


- Full function
- Frequency: 27MHz
- Range up to 100 ft

## Assembling R/C Dolphin Surfer

Screw the antenna into the top of the controller. Tighten finger tight. (Do not overtighten.)




Please insert the Dolphin fins, according to the numbers marked on the back of the fins, into the holes on two sides of RC Dolphin Surfer.




## Charging The R/C Dolphin Surfer Battery

- 1 Use a screwdriver(not included) to unscrew the rechargeable battery pack door at the bottom of the RC Dolphin Surfer.
- 2 Plug AC Adapter into standard wall outlet.
- 3 Plug AC Adapter lead into the rechargeable battery pack.
- 4 Charge the battery for about 4-5 hours for the first time. For the next time you decide to play with the unit, charge the battery for 2 hour.
- 5 Unplug battery pack from AC adapter, then AC Adapter from wall outlet.




## Battery Installation

- 1 Make sure the rechargeable battery is fully charged.
- 2 Turn off the RC Dolphin Surfer switch at the bottom of the unit.
- 3 Connect the rechargeable battery pack to the battery compartment and then place the battery pack inside with the battery pack door cover the battery compartment.
- 4 Use a screwdriver(not included) to screw the battery pack door tightly to close.



- 1 Turn off the controller.
- 2 Slide open and remove the back cover on the controller.
- 3 Insert 8 "AA" size 1.5V batteries in the correct polarity and replace cover.



## BATTERY CONTACTS

Bent or dirty battery contacts may result in loss of power.

ON/OFF switch

8 x size "AA" LR6 1.5V batteries


## Battery Requirement

- One 9.6V A size 2100mAh rechargeable battery pack for RC Dolphin Surfer. (Included in this package)
- 8 "AA" size 1.5V batteries for radio controller. (Note: For the best performance and longer play time, ALKALINE batteries are recommended. Batteries are not included in this package.)

## How To Operate R/C Dolphin Surfer


- Turn on the controller, the LED light will turn on.
- Turn on the RC Dolphin Surfer switch at the bottom of the unit.
- Use the controller's levers to control the movement and direction of RC Dolphin Surfer.

## Trick 2




Step 1 - Push lever "A" up to swim forward.  
Step 2 - Turn lever "B" up/down and hold for 5 seconds.  
Now RC Dolphin Surfers can make as many spins as you want it to.

[A] + [B] (Hold B for 5 seconds)



OR



[A] + [B] (Hold B for 5 seconds)



LED Power Indicator

## Trick 1

Step 1 - Push lever "A" forward and hold for a few seconds.  
Step 2 - Pulse lever "B" left and right to keep RC Dolphin Surfer slapping its fins in the water.




Step 1 - Push lever "A" up to swim forward.  
Step 2 - Turn lever "B" up/down and hold for 5 seconds.  
Now RC Dolphin Surfers can make as many spins as you want it to.

LED Power Indicator

### CAUTION

- RC Dolphin Surfer is designed for operation in fresh water. Pools and lakes are recommended. Do not use in salt water or brackish water.
- Do not immerse the RC Dolphin Surfer in water unless the battery compartment cover is properly closed.
- Do not expose the radio controller to water. If the controller is accidentally exposed to water, remove the controller battery and allow the controller to dry completely before use.
- Keep fingers, hair and loose clothing away from the propeller drive with the vehicle is switched ON. To prevent entanglement, keep hair away from propeller. (Diagram 2)
- DO NOT pick up vehicle while in motion.
- Adult supervision is recommended when this vehicle is being operated.
- To avoid accidental operation, remove all batteries when not in use.
- Do not touch the fins of RC Dolphin Surfer as this may affect its performance.
- Do not use the RC Dolphin Surfer as a toy. It is not intended for use as a toy.
- Transformers used with the toy are to be regularly examined for damage to the cord, plug, enclosure and other parts, and that, in the event of such damage, the toy must not be used until the transformer and the damage have been repaired.
- Do not operate near swimmers.
- Stand away from the water's edge when operating.



### FCC RULES

This device complies with the Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur. In a particular installation, if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

### Quick Start

1. Start with fresh batteries (for a full charge).
2. Turn vehicle switch ON. Press controller controls to run and control RC Dolphin Surfer.
3. When you're done driving, turn vehicle power switch OFF.
4. Remove all batteries for storage.

### Helpful Hints

1. Only 2 RC Dolphin Surfers in different frequencies can run or race together.
2. If your RC Dolphin Surfer moves slowly or does not move at all, replace the batteries with fresh ones.
3. If the motor runs but the RC Dolphin Surfer does not respond to the controller, replace the controller's batteries.
4. For better performance, hold controller antenna upright and point at RC Dolphin Surfer. If your vehicle gets too far away, it will not work properly.
5. After use, take the RC Dolphin Surfer out of water and set the ON/OFF switch to OFF.
6. If you are using the RC Dolphin Surfer, remove the batteries. Never leave weak or dead batteries in the RC Dolphin Surfer and/or controller.
7. When RC Dolphin Surfer is completely dry, the result of interference caused by high tension wires, CB radios, or other RC vehicles running nearby, on the same frequency as yours. You may have to choose an alternative place to play.
8. After each use, dry the RC Dolphin Surfer thoroughly and remove water or moisture from it using a clean dry cloth before storing.
9. Always turn switches OFF and remove all batteries for storage.
10. Put the RC Dolphin Surfer in upright position to drain water from the hull. (Diagram A)
11. Leave the RC Dolphin Surfer's battery compartment cover open to allow moisture to evaporate while it is in storage.
12. After about 2 minutes of running time, you should pay close attention to RC Dolphin Surfer's location, making sure that it's close to you.
13. When your vehicle starts to perform poorly, it's time for fresh batteries. (for a recharge) Your vehicle's running time may change depending on your driving style.



### Note to Adult

The AC Adapter is age graded for ages 12 and over. The AC adapter is not a toy. The AC Adapter should not be operated by anyone under age 12, unless supervised by an adult. As with all electronic products, precautions should be observed during handling and use to prevent electric shock. Periodically inspect the adapter and replace any part found defective before using.

### BATTERY CAUTION

1. Batteries may heat during use and can cause a chemical burn injury or melt your toy. To avoid battery damage, always follow the instructions carefully.
2. Use only batteries specified and be sure to insert them correctly by the + and - polarity markings. Always check the on and off battery compartment's instructions.
3. Remove batteries when not in use. Always remove exhausted batteries from RC Dolphin Surfer and controller. Disposed batteries should be recycled properly.
4. Recharge batteries in a well-ventilated area. Always remove exhausted batteries from RC Dolphin Surfer and controller. Disposed batteries should be recycled properly.
5. Recharge batteries in a well-ventilated area. Always remove exhausted batteries from RC Dolphin Surfer and controller. Disposed batteries should be recycled properly.
6. Recharge batteries in a well-ventilated area. Always remove exhausted batteries from RC Dolphin Surfer and controller. Disposed batteries should be recycled properly.
7. Recharge batteries in a well-ventilated area. Always remove exhausted batteries from RC Dolphin Surfer and controller. Disposed batteries should be recycled properly.
8. Do not charge the battery in a confined space or near flammable materials.
9. Do not charge the battery in a confined space or near flammable materials.
10. Do not charge the battery in a confined space or near flammable materials.
11. Never charge the battery in a confined space or near flammable materials.
12. Always unplug AC adapter when not in use.
13. Never leave rechargeable battery unattended when charging.
14. Do not attempt to charge a battery that is damaged or swollen.
15. Do not attempt to charge a battery that is leaking or has a strong odor.
16. If the rechargeable battery pack is HOT, allow it to cool before charging or using.
17. Never mix and match different types of batteries.
18. Do not attempt to charge a battery that is leaking or has a strong odor.
19. Do not attempt to charge a battery that is leaking or has a strong odor.
20. Do not attempt to charge a battery that is leaking or has a strong odor.
21. Do not attempt to charge a battery that is leaking or has a strong odor.
22. Never touch the battery pack or the battery pack's terminals.
23. Do not attempt to charge a battery that is leaking or has a strong odor.
24. Should the battery pack or the battery pack's terminals be damaged, stop using it immediately.
25. Do not attempt to charge a battery that is leaking or has a strong odor.
26. Do not attempt to charge a battery that is leaking or has a strong odor.
27. Do not attempt to charge a battery that is leaking or has a strong odor.
28. Do not attempt to charge a battery that is leaking or has a strong odor.
29. Do not attempt to charge a battery that is leaking or has a strong odor.
30. Do not attempt to charge a battery that is leaking or has a strong odor.
31. Do not attempt to charge a battery that is leaking or has a strong odor.
32. Do not attempt to charge a battery that is leaking or has a strong odor.
33. Do not attempt to charge a battery that is leaking or has a strong odor.
34. Do not attempt to charge a battery that is leaking or has a strong odor.
35. Do not attempt to charge a battery that is leaking or has a strong odor.
36. Do not attempt to charge a battery that is leaking or has a strong odor.
37. Do not attempt to charge a battery that is leaking or has a strong odor.
38. Do not attempt to charge a battery that is leaking or has a strong odor.
39. Do not attempt to charge a battery that is leaking or has a strong odor.
40. Do not attempt to charge a battery that is leaking or has a strong odor.
41. Do not attempt to charge a battery that is leaking or has a strong odor.
42. Do not attempt to charge a battery that is leaking or has a strong odor.
43. Do not attempt to charge a battery that is leaking or has a strong odor.
44. Do not attempt to charge a battery that is leaking or has a strong odor.
45. Do not attempt to charge a battery that is leaking or has a strong odor.
46. Do not attempt to charge a battery that is leaking or has a strong odor.
47. Do not attempt to charge a battery that is leaking or has a strong odor.
48. Do not attempt to charge a battery that is leaking or has a strong odor.
49. Do not attempt to charge a battery that is leaking or has a strong odor.
50. Do not attempt to charge a battery that is leaking or has a strong odor.
51. Do not attempt to charge a battery that is leaking or has a strong odor.
52. Do not attempt to charge a battery that is leaking or has a strong odor.
53. Do not attempt to charge a battery that is leaking or has a strong odor.
54. Do not attempt to charge a battery that is leaking or has a strong odor.
55. Do not attempt to charge a battery that is leaking or has a strong odor.
56. Do not attempt to charge a battery that is leaking or has a strong odor.
57. Do not attempt to charge a battery that is leaking or has a strong odor.
58. Do not attempt to charge a battery that is leaking or has a strong odor.
59. Do not attempt to charge a battery that is leaking or has a strong odor.
60. Do not attempt to charge a battery that is leaking or has a strong odor.
61. Do not attempt to charge a battery that is leaking or has a strong odor.
62. Do not attempt to charge a battery that is leaking or has a strong odor.
63. Do not attempt to charge a battery that is leaking or has a strong odor.
64. Do not attempt to charge a battery that is leaking or has a strong odor.
65. Do not attempt to charge a battery that is leaking or has a strong odor.
66. Do not attempt to charge a battery that is leaking or has a strong odor.
67. Do not attempt to charge a battery that is leaking or has a strong odor.
68. Do not attempt to charge a battery that is leaking or has a strong odor.
69. Do not attempt to charge a battery that is leaking or has a strong odor.
70. Do not attempt to charge a battery that is leaking or has a strong odor.
71. Do not attempt to charge a battery that is leaking or has a strong odor.
72. Do not attempt to charge a battery that is leaking or has a strong odor.
73. Do not attempt to charge a battery that is leaking or has a strong odor.
74. Do not attempt to charge a battery that is leaking or has a strong odor.
75. Do not attempt to charge a battery that is leaking or has a strong odor.
76. Do not attempt to charge a battery that is leaking or has a strong odor.
77. Do not attempt to charge a battery that is leaking or has a strong odor.
78. Do not attempt to charge a battery that is leaking or has a strong odor.
79. Do not attempt to charge a battery that is leaking or has a strong odor.
80. Do not attempt to charge a battery that is leaking or has a strong odor.
81. Do not attempt to charge a battery that is leaking or has a strong odor.
82. Do not attempt to charge a battery that is leaking or has a strong odor.
83. Do not attempt to charge a battery that is leaking or has a strong odor.
84. Do not attempt to charge a battery that is leaking or has a strong odor.
85. Do not attempt to charge a battery that is leaking or has a strong odor.
86. Do not attempt to charge a battery that is leaking or has a strong odor.
87. Do not attempt to charge a battery that is leaking or has a strong odor.
88. Do not attempt to charge a battery that is leaking or has a strong odor.
89. Do not attempt to charge a battery that is leaking or has a strong odor.
90. Do not attempt to charge a battery that is leaking or has a strong odor.
91. Do not attempt to charge a battery that is leaking or has a strong odor.
92. Do not attempt to charge a battery that is leaking or has a strong odor.
93. Do not attempt to charge a battery that is leaking or has a strong odor.
94. Do not attempt to charge a battery that is leaking or has a strong odor.
95. Do not attempt to charge a battery that is leaking or has a strong odor.
96. Do not attempt to charge a battery that is leaking or has a strong odor.
97. Do not attempt to charge a battery that is leaking or has a strong odor.
98. Do not attempt to charge a battery that is leaking or has a strong odor.
99. Do not attempt to charge a battery that is leaking or has a strong odor.
100. Do not attempt to charge a battery that is leaking or has a strong odor.

If there is any problem with RC Dolphin Surfer, please call our customer service hotline: (852) 2793 1288. Please do not return goods to retail store directly.



[A] + [B] [B]



Manufactured and distributed by © 2008 ACK Ltd. All Rights Reserved.  
ACK Ltd. (Head Office): Unit 107, 13/F, Lam Tin Centre, 50 Ho Yuen Road, Kwan Tong, Kowloon, Hong Kong

Printed in China

