

Portable Bluetooth Speaker

BlueBoo

Instruction Manual



Included Items:


- Speaker
- Micro USB Charging Cable
- Auxiliary/AUX Cord

Before using your speaker, connect to power source and charge speaker. The initial charge should take approximately 2-1/2 hours.

Charging Instructions:

1. Connect the Micro USB charging Cable to a USB Port.
2. Red light indicates speaker is in charging mode.
3. No light indicates full charge complete.
4. Once fully charged, play time is approximately 3 hours.

Note: The speaker will beep when it is down to 10% power to indicate charging is needed.



Powering Speaker ON/OFF:

Press and hold the Power Button for 3 seconds to power ON and OFF. When speaker is not in use, power device off to preserve battery power.

Pairing Your Device:

1. Press and hold the Power Button.
2. You will hear one beep and a blue light will start flashing. Continue holding the Power Button and wait for the second beep and the red/blue light to begin flashing.
3. At this point the speaker is discoverable and ready to pair to your device.
4. On your device, set your Bluetooth capability to discoverable.
5. On your Bluetooth device list, select BlueBoo (this is the name for all speakers).
6. Once paired, your device should link to the speaker whenever in 30 foot range.


Note: Speaker can be paired with only one device at a time.

Playing music:

1. Turn on speaker and pair your device (see previous sections).

2. If previously paired, speaker will flash blue light indicating that it is searching for your device.

3. Use your device to start play of music.
4. For Bluetooth paired mode, use arrows on speaker to skip back and forth to navigate songs. Use your device to control volume.
5. For Auxiliary mode, press and hold arrows to control volume. Use your device to navigate songs.



FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.