


Installation guide

XS4 One S for European mortise locks


SALTO
inspired^{access}

- (Eng) Installation guide
(E) Guía de instalación
(D) Montageanleitung
(F) Guide d'installation
(I) Guida all'installazione
(P) Guia de instalação


E i 950 xx series



E i 9xx.. series		E i 9xx..E5 series	
OUTSIDE	INSIDE	OUTSIDE	INSIDE
IP54	IP44	IP56	IP44



SALTO recommends the use of a mortise lock, with a maximum 4° pre-turn.
SALTO recommande d'utiliser des serrures à mortaiser avec un angle au repos de 4° maximum.
SALTO recomienda utilizar cerraduras con un pregiro máximo de 4°.



	Door thickness	t	
		L	
3	32 - 47mm	35 mm	-
4	45 - 60 mm	50 mm	-
6	60 - 75 mm	30 mm	x2
7	75 - 90 mm	45 mm	x2
9	90 - 105 mm	30 mm	x4
1	105 - 120 mm	45 mm	x4
2	32 - 53 mm	35 mm	-
A		35 mm	-
B		45 mm	-
5		45 mm	-


MODEL: ELECTRONIC INFO. W60M - W60T - W60MH

Installation guide


XS4 One S for European mortise locks

SALTO
inspired access

(Eng) Select handing (E) Seleccione mano (D) Drückerrichtung wählen (C) Choisir le sens de la bêche
(I) Scegliere il verso (P) Seleccione mão



(Eng) Installation (E) Instalación (D) Installation (F) Installation (I) Installazione (P) Instalação




Installation guide



XS4 One S for European mortise locks

SALTO
inspiredaccess


4




5




6




7



8





9



- ⚠**
- AT THIS POINT DO NOT
CLOSE THE DOOR
PROGRAM THE LOCK FIRST**
- NO CIERRE LA PUERTA.
PROGrame LA CERRADURA**
- TÜR NICHT SCHLIESSEN.
ZUERST SCHLOSS
PROGRAMMIEREN**
- NE FERMEZ PAS LA PORTE.
PROGRAMMEZ LA BÉQUILLE
AVANT**
- PROGRAMARE LA SERRATURA
PRIMA DI CHIUDERE LA PORTA**

Eng Battery change
F Remplacer les piles
E Cambio de pilas



Change/Remplacer/Cambio




Installation guide

XS4 One S for European mortise locks

SALTO
inspired^{access}

E i 951 xx.. series


E i 9P1 xx.. series



Eng Other models E Otros modelos D Andere Modelle F D'autres modèles I Altri modelli P Outros modelos


E i 956 xx..

- Eng -Entry lock with privacy/ lockout funtion
- E -Modelo entrada con privacidad
- D -Beschlag mit Privacy-Funktion
- F -Béquille électronique avec fonction privacité
- I -Modelo di entrata con privacy
- P -Modelo entrada com privacidade



E i 9P6 xx..

- Eng -Entry lock with privacy/lockout funtion and key override
- E -Modelo entrada con privacidad y llave de emergencia con registro
- D -Beschlag mit Privacy-Funktion und Notschlüssel
- F -Béquille électronique avec fonction privacité et clef de secours
- I -Modelo entrada con privacy e chiave di emergenza con registrazione
- P -Modelo entrada com privacidade e chave de emergencia com registro



E T9xx.. series

