
# **EXHIBIT C - EUT INTERNAL PHOTOGRAPHS**


Antenna

### **EUT – Cover off View 1**







**EUT – Cover off View 3** 




**EUT – Main Board 1 Top View** 




**EUT – Main Board Top 1 Shielding off View** 



**EUT – Main Board 1 Bottom View** 




**EUT – Main Board Bottom 1 Shielding off View** 



**EUT – Main Board 2 Top View** 



**EUT – Main Board 2 Bottom View** 




**EUT – Main Chip 1 View** 



**EUT – Main Chip 2 View** 



**EUT – Battery View** 



## **EUT – Battery Label View**

#### **CAUTION**

- Do not expose to high temperature (140°F/60°C).
- Do not disassemble.
   Do not allow metal objects to contact or short circuit the battery terminals.
- Do not incinerate or expose to fire. To dispose of property.

### **PRECAUCION**

- 60°C(140°F) No la desarme.
- No deje objectos metálicos en contacto o corto circuito las baterias terminales.
  - No la incinere o exponga al fuego.
  - Se deshaga apropiadamente.

### **Wrong Way**

Turn battery over to insert. Dirección Equivocada. Inserte la batería al revés.

