

<div data-bbox="636 408 808 480" data-label="Section-Header"> <h1>MAGNET HS</h1> <h2>Quick guide</h2> </div>	<div data-bbox="920 196 1016 212" data-label="Section-Header"> <h3>Usage method</h3> </div> <div data-bbox="920 226 1016 239" data-label="Section-Header"> <h4>Connect Bluetooth</h4> </div> <div data-bbox="920 240 1256 320" data-label="Text"> <p>Remove the remote control, Long press the shutter/power button for 3s to turn on the remote control,then the indicator light flashes green, and then turn on mobile phone Bluetooth to enter the search state,select "SEURUM" from the list of available devices and the green light will be change from flashing green to steady green after the connection succeeds.</p> </div> <div data-bbox="920 328 1211 443" data-label="Image"> </div> <div data-bbox="920 454 981 467" data-label="Section-Header"> <h4>Use a tripod</h4> </div> <div data-bbox="920 469 1249 537" data-label="Text"> <p>After opening the support, ① hold the support with one hand and press the bottom triangle button with one hand, the three legs of the tripod will automatically open, pull the tripod, the tripod is completely open, and the ② tripod is used on a smooth horizontal surface.</p> </div> <div data-bbox="920 539 1227 738" data-label="Image"> </div>
<div data-bbox="555 778 622 791" data-label="Section-Header"> <h4>Device phone</h4> </div> <div data-bbox="555 793 884 861" data-label="Text"> <p>The magnetic ring on the back of the mobile phone is automatically absorbed or fixed with the mobile phone clip (Note: the magnetic ring adsorption is only applicable to the mobile phone with the magnetic sheet, other mobile phones please use the bracket to fix) The magnetic ring can be used horizontally and vertically.</p> </div> <div data-bbox="568 868 869 1038" data-label="Image"> </div> <div data-bbox="555 1045 678 1058" data-label="Section-Header"> <h4>Camera and video mode</h4> </div> <div data-bbox="555 1059 873 1088" data-label="Text"> <p>This product can be hand-held self-portrait, can also use tripod mode video or live broadcast.</p> </div> <div data-bbox="568 1094 860 1294" data-label="Image"> </div>	<div data-bbox="920 778 1016 791" data-label="Section-Header"> <h4>Charge description</h4> </div> <div data-bbox="920 793 1256 981" data-label="List-Group"> <ul style="list-style-type: none"> ●Insert the Type-C cable into the charging port of the remote control to charge it when the battery capacity of the remote control is insufficient. ●Low battery prompt: Please charge it as soon as possible when the red light starts to flicker ●Dormant State:After the remote control is turned on,it will enter the dormant state and the flicker light will be off;if it is not connected to Bluetooth within 10 minutes,Also the remote will enter the dormant state;if it is connected to Bluetooth successfully but not be operated within 10 minutes,and then it will automatically turn off if not be operated within 30 minutes. ●Awakening from the dormant state: In the dormant state, the camera indicator light will be on once by short pressing the shutter button, and then enter the pairing flicker state. </div> <div data-bbox="987 991 1182 1121" data-label="Image"> </div> <div data-bbox="920 1150 967 1163" data-label="Section-Header"> <h4>Warnings</h4> </div> <div data-bbox="920 1165 1249 1300" data-label="List-Group"> <ol style="list-style-type: none"> 1. Watch your hands during use. 2. To protect your equipment, keep the tripod in a stable state and prevent other external forces from tipping the tripod over. 2. The product is not designed for children under 14 years old.Do not swallow it. 3. Do not dismantle or modify the product. 4. Do not store the product in a humid environment. 5. Keep the product away from heat sources. 6. Do not expose the product to water or other liquids in case of damage. </div>

FCC ID:UR9WS-23003

FCC statements:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

尺寸：70*105mm
材质：80g书纸