

User Manual

Model: RF*-2-*-*

Transmitter Battery: 9 Volt, Model 6F22 or the equivalent

1. Intended use: For control of the fan and light kit, or other electrical appliance.
2. Operation guide
 - 2.1 Install 9 Volt battery (6F22) before operating.
 - 2.2 Set the code switches to the same positions as set on the receiver before Installing the battery in Series RFS-2-*-* (see figure 1)
 - 2.3 The Transmitter can be operated when the battery has been installed accurately. Its operation is the same as other remote controllers, choose the function button and tap it, the receiver will perform the corresponding command.
3. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

The operating range is 15-30 feet.

FCC NOTE:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

