


# Manual

We appreciate your purchase of the HP-WH600 wireless soundbox.

This manual will give you all the necessary information to rid your home of unwanted pests, safely and effectively. Please read this manual carefully and keep it for future reference.

## Product overview



## Product introduction

- Supports all type of portable audio /video devices MP3/MP4 Players CD Players etc
- With 3.5mm Audio connector to Plug your MP3/MP4 and other Audio Players
- With a DC pin to connect the adapter for DC 12V power
- With 6\*AAA Batteries into the battery compartment at the back of the unit .
- Connect the Transmitter input Jack to your Portable Device output jack

## **Specification**

Modulation type: FM

FIX frequency: 49.85MHz FM

Antenna impedance : 50Ω

RF output power:≤100dBu

Consume current: max 75mA

### **Warnings:**

Do not mix alkaline,standard (carbon-zinc) or rechargeable (nickel cadmium) batteries.

Do not mix old and new batteries.

Do not dispose of batteries in a fire.

Do not attempt to recharge ordinary batteries.

Batteries may explode or leak

### FCC NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT.

SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation