



Label location

unit : mm




Bottom-Label for IBR600E-SP

unit : mm




Bottom-Label for IBR600LE-VZ

unit : mm




Bottom-Label for IBR600LP-AT

unit : mm




Bottom-Label for IBR600P

unit : mm




Bottom-Label for IBR600LP-AT-PWD

unit : mm



Bottom-Label for IBR600LE-VZ-PWD

unit : mm



Bottom-Label for IBR600NM