


Instruction Guide



Step By Step

- i) Connect Dongle with your PC USB port, Windows system will automatically detect a new hardware and complete the setup.
- ii) Open Battery Compartment Cover, load a AA battery (Alkaline cell suggested, ensure correct polarity)
- iii) Switch on the mouse (Power Switch)

- iv) Wireless mouse is on working now
- v) Pressing CPI Shifter can change mouse CPI, this can change the mouse cursor moving speed on your PC screen.

Technical Parameters (2.4G Wireless Mouse)

Model NO.	EM10577		
Dimension	94L*65W*36H(mm)	Battery	1 AA /1.5V
Technology	2.4G wireless RF	Power	0.045W
Frequency	2403~2479MHz	V/A	1.5V/30mA

Technical Parameters (2.4G RF Dongle)

Model NO.	EM10578		
Technology	2.4G wireless RF	Power	0.2W
Frequency	2403~2479MHz	V/A	5V/40mA

Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.