



Battery 4 (Wireless Battery)








Battery 5 (1x)








USB TYPE A to TYPE C cable



USB TYPE C to 3.5mm audio connector





3.5mm Earphone





Rugged Headset





USB TYPE C Earphone





Trigger Handle





Soft Holster





TC53/TC58 RUGGED BOOT





3.5mm to 3.5mm audio connector

