



1. External Photograph of EUT

Brand Name: Zebra / Model Name: TC7301

Sample 1















Sample 2













Sample 3















2. Photograph of Accessory

Brand Name: Zebra / Model Name: TC7301

Specification of Accessory		
Adapter	Brand Name	Zebra
	Part Number	PWR-WUA5V12W0US
Battery 1X	Brand Name	Zebra
	Part Number	BT-000442-0020
Battery 1.5X	Brand Name	Zebra
	Part Number	BT-000442-0820
Wireless Battery	Brand Name	Zebra
	Part Number	BT-000442-002A
USB TYPE A to TYPE C cable	Brand Name	Zebra
	Part Number	CBL-TC5X-USBC2A-01
USB TYPE C to 3.5mm audio connector	Brand Name	Zebra
	Part Number	ADP-USBC-35MM1-01
3.5mm Earphone	Brand Name	Zebra
	Part Number	HDST-35MM-PTVP-01
USB TYPE C Earphone	Brand Name	Zebra
	Part Number	HPST-USBC-PTT1-01
Trigger Handle	Brand Name	Zebra
	Part Number	TRG-NGTC5-ELEC-01
Soft Holster	Brand Name	Zebra
	Part Number	SG-NGTC5TC7-HLSTR-01
TC53/TC58 RUGGED BOOT	Brand Name	Zebra
	Part Number	SG-NGTC5EXO1-01

Remark: For accessories equipped with this EUT, please refer to the following photos.



Adapter



Battery 1X



Battery 1.5X



Wireless Battery

