



SKU 3-2










































SKU 4












































2. Photograph of Accessory

Brand Name: Zebra / Model Name: WS5001

Specification of Accessory		
Adaptor	Brand Name	Zebra
	Model Number	PWR-WUA5V12W0US
Battery 1x	Brand Name	Zebra
	Model Number	BT-000446
Battery 1.6x	Brand Name	Zebra
	Model Number	BT-000446B
USB charging cable with cup	Brand Name	Zebra
	Model Number	CBL-WS5X-USB1-01
USB C CABLE	Brand Name	Zebra
	Model Number	BL-TC2X-USBC-01

Remark: For accessories equipped with this EUT, please refer to the following photos.



Adaptor



Battery 1x



Battery 1.6x

