


1. External Photograph of EUT

Brand Name: Zebra / Model Name: WT0

Sample 1


















Sample 2



















2. Photograph of Accessory

Brand Name: Zebra / Model Name: WT0

Specification of Accessories				
AC Adapter	Brand Name	Zebra	Part Number	PWR-WUA5V12W0US
Corded Adapter 1	Brand Name	Zebra	Part Number	CBL-RS5X6-ADPWT-01
Corded Adapter 2	Brand Name	Zebra	Part Number	CBL-RS5X6-ADPCT-01
Battery 1	Brand Name	Zebra	Part Number	BT-000490-1020
Battery 2	Brand Name	Zebra	Part Number	BT-000490-1820
USB Cable	Brand Name	Zebra	Part Number	CBL-NGWT-USBCHG-01
Vibrating Cable	Brand Name	Zebra	Part Number	CBL-NGWT-HDVBAP-01
Type-C cable	Brand Name	Zebra	Part Number	CBL-EC5X-USBC3A-01
Type-A to Type-C cable	Brand Name	Zebra	Part Number	CBL-TC5X-USBC2A-01
Audio Cable 1	Brand Name	Zebra	Part Number	CBL-HS2100-12S1-01
Audio Cable 2	Brand Name	Zebra	Part Number	CBL-HS3100-CUC1-01
Training cable	Brand Name	Zebra	Part Number	25-129938-02R
Audio Adapter Cable (Short)	Brand Name	Zebra	Part Number	CBL-NGWT-AUQDST-02
Audio Adapter Cable (Long)	Brand Name	Zebra	Part Number	CBL-NGWT-AUQDLG-01
HEADSET QUICK DISCONNECT CABLE	Brand Name	Zebra	Part Number	CBL-HS2100-QDC1-02
Scanner 1	Brand Name	Zebra	Part Number	RS61B0-KESSZWR or RS61B0-KESSXWR
			Model Number	RS6100
Scanner 2	Brand Name	Zebra	Part Number	RS51B0-xxxxWR
			Model Number	RS5100
Scanner 3	Brand Name	Zebra	Part Number	RS4000-HPCSWR
			Model Number	RS4000
Scanner 4	Brand Name	Zebra	Part Number	RS4000-HPCLWR
			Model Number	RS4000
Scanner 5	Brand Name	Zebra	Part Number	RS5000-LCFLWR
			Model Number	RS5000
Earphone 1	Brand Name	Zebra	Model Number	HS2100
Earphone 2	Brand Name	Zebra	Model Number	HS3100
Earphone 3	Brand Name	Zebra	Part Number	HDST-USBC-PTT1-01
hip mount 1	Brand Name	Zebra	Part Number	SG-WT5X6-HPMNT-01
hip mount 2	Brand Name	Zebra	Part Number	SG-WT5X6-HPMTX-01



Specification of Accessories				
Dual dial strap (S)	Brand Name	Zebra	Part Number	SG-WT5X6-WSTDS-01
Dual dial strap (L)	Brand Name	Zebra	Part Number	SG-WT5X6-WSTDL-01
Dual dial strap (XL)	Brand Name	Zebra	Part Number	SG-WT5X6-WSTDX-01
Velcro strap (S)	Brand Name	Zebra	Part Number	SG-WT5X6-WSTVS-01
Velcro strap (L)	Brand Name	Zebra	Part Number	SG-WT5X6-WSTVL-01
Velcro strap (XL)	Brand Name	Zebra	Part Number	SG-WT5X6-WSTVX-01
Single dial strap (S)	Brand Name	Zebra	Part Number	SG-NGWT-WSTPST-01
Single dial strap (L)	Brand Name	Zebra	Part Number	SG-NGWT-WSTPLN-01
Single dial strap (XL)	Brand Name	Zebra	Part Number	SG-NGWT-WSTPXL-01
sleeves for wrist mount	Brand Name	Zebra	Part Number	SG-WT4027050-01R
Screen Protector	Brand Name	Zebra	Part Number	MISC-WT5X6-SCRN-05
Wrist mount + Single dial strap (S)	Brand Name	Zebra	Part Number	SG-WT5X6-WMTSS-01
Wrist mount + Single dial strap (L)	Brand Name	Zebra	Part Number	SG-WT5X6-WMTSL-01
Wrist mount + Single dial strap (XL)	Brand Name	Zebra	Part Number	SG-WT5X6-WMTSX-01
Wrist mount + Dual dial strap (S)	Brand Name	Zebra	Part Number	SG-WT5X6-WMTDS-01
Wrist mount + Dual dial strap (L)	Brand Name	Zebra	Part Number	SG-WT5X6-WMTDL-01
Wrist mount + Dual dial strap (XL)	Brand Name	Zebra	Part Number	SG-WT5X6-WMTDX-01
Wrist mount + Velcro strap (S)	Brand Name	Zebra	Part Number	SG-WT5X6-WMTVS-01
Wrist mount + Velcro strap (L)	Brand Name	Zebra	Part Number	SG-WT5X6-WMTVL-01
Wrist mount + Velcro strap (XL)	Brand Name	Zebra	Part Number	SG-WT5X6-WMTVX-01

Remark: For accessories equipped with this EUT, please refer to the following photos.



AC Adapter



Corded Adapter 1







Corded Adapter 2






Battery 1









Battery 2





