




MYSTIGLO™

LED Open Sign Instructions

Item No. 283158
Model No. AA-04-RC

Installation

1. Remove "S" hooks and chains from the parts bag located within the packaging.
2. Install the two "S" hooks through the hanger tabs located on the top of the open sign.
3. Attach the chains to the "S" hooks. [FIGURE A]
4. Attach the two chains to the ceiling using the appropriate hanging hardware.
5. Insert barrel plug into power input and plug adaptor into the electrical outlet.
6. Remove battery tab on remote.



Remote [FIGURE B]

WARNING: Flash/Remote – Static Switch on control panel MUST be positioned to Flash/Remote for remote to function.

Includes one 27A battery.

ON / OFF
FLASH / STATIC
FLASH SPEED

Remote range:
32' with antenna up
12' with antenna down



FIGURE B

REPLACEMENT REMOTES:

- Only \$9.00 each
- Free Shipping
- Easy to program
- To order call 1-877-264-5625

Control Panel

on back of sign – [FIGURE C]

Flash/Remote - Power Switch

Switch MUST be positioned to Flash/Remote for remote to function

Flash Speed Control

Push to change speeds (eight speed options)

Power

Input Volts: 120VAC
Hertz: 60Hz
Output Amps: 1500mA
Output Volts: 18VDC



FIGURE C

CAUTION

To reduce the risk of fire, electric shock or injury to persons:

- This product is for indoor use only. Do not use in damp or wet locations.
- Not for use with light dimmer circuits.
- To reduce the likelihood of injury or damage mount only on a surface that is mechanically sound.
- Do not use extension cords or outlets with inadequate current carrying capacity.
- It is recommended to use a surge protector. Power surges ARE NOT covered under warranty for this product.
- Only use 120VAC input, 60Hz, 18VDC, 1500mA output adaptor.
- Do not handle adapter or sign with wet hands.
- Disconnect power before handling or cleaning.
- Do not use liquid cleaners or aerosol cleaners. Use a dry cloth for cleaning.
- This product is fully assembled and ready to use. Do not attempt to disassemble or service.
- Do not alter the plug or power supply cord in any way.



LED Open Sign LIMITED 3 YEAR WARRANTY

Model Number : AA-04-RC

Part Number: 283158

C-M Glo, LLC warrants that this product will be free from defect due to material and workmanship under normal use for a period of three (3) years from the date of purchase. Please retain receipt for proof of purchase. Proof of purchase is required for any warranty claim. Warranty is void if product is abused, disassembled, or exposed to atmosphere or conditions other than stated within instructions. If product fails within the specified time, return the product to the store where it was purchased or return sign with all accessories, original packing material and a copy of the sales receipt to C-M Glo, LLC. Your sign will be repaired or replaced within six weeks of receipt of your unit. Please ship your sign to:

**C-M Glo, LLC
1201 N. 4th Street
Watertown, WI 53098
(920) 261-1000**

DISCLAIMER OF WARRANTY

Warranty is invalid if purchaser fails to properly operate and/or maintain the product. This Warranty is not transferable to third parties. There is no warranty for fitness for a particular purpose. This Warranty is in lieu of all other warranties expressed or implied. No representative or any other person is authorized or permitted to make any Warranty changes or assume on behalf of C-M Glo, LLC any liability not strictly in accordance with this Warranty.

C-M Glo, LLC shall not be liable for special or consequential loss or damages, direct or indirect, such as, but not limited to, damage or loss of property or equipment, loss of profit or revenue, loss of use of the product, cost or replacement of the product, or claims for service interruptions.

Tampering, accident, abuse, negligence, unauthorized repairs, or other causes unrelated to defective materials or workmanship will void this Warranty. This warranty does not cover costs associated with shipping the product to the manufacturer. This warranty does not cover replacement of remote battery.

FCC ID: V2S-TV4LN

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.