



Game2Gear RFID Reader Operating Instructions

Connect supplied USB cable to a USB port on your PC. Connect the small connector on the USB cable to your Game2Gear RFID Reader. A Red LED should illuminate on the reader indicating that the reader is receiving power from the USB Port, and a Green LED should slowly pulsate, indicating that the reader is functional and ready to scan your item.

Log onto (URL address here). Once logged onto the website, a Game 2 Gear Reader interface should appear on your Monitor. If not, insure that your Internet Browser allows downloading of ActiveX controls. In Internet Explorer, a yellow bar will appear at the top of the webpage. Click on this bar, and you will be given the option to allow the download.

The Game 2 Gear Reader Interface will prompt you to do what is necessary. First it will indicate that it is searching for the attached reader. If it cannot find it, it will prompt you to connect. Once the connection with the reader has been established, you will be prompted to scan your item.

Scan your item by passing the reader over the item. When the Authentication Chip within your item has been located, the Green LED on the reader will begining to flash rapidly.

The scan is now complete. Your Game 2 Gear Interface will now confirm the authenticity of your item.

CAUTION TO THE USER

Changes or modifications to the Game 2 Gear Reader not expressly approved by Game 2 Gear shall void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.