



USER GUIDE

Euphonia™ System

 BainUltra®

The Original Air Jet Bath & Home Spa™

USER GUIDE

Synchronizing headset with MP3 module

- Make sure the headset is at least 1 meter (3.2') from the MP3 player.
- Press the MP3 player button. The LED light should start flashing quickly.
- Press simultaneously on « + » and « - » until you hear a single beep in the headset.
- After a few seconds, a two-beep audible signal (beep-beep) will sound.
- The headset is now synchronized with the MP3 player.

Turning on the headset


Hold down the “+” key for about 3 seconds until you hear a three-beep audible signal (beep-beep-beep). After a few seconds, the headset will detect the MP3 player signal and you will hear two beeps. If music is playing, you will hear it.

If the bathtub is not turned on, the headset will not detect the MP3 player and it will automatically power off.

1 800 463.2187 

From 8 a.m. to 8 p.m. Monday to Thursday (EST)
From 8 a.m. to 5 p.m. on Friday (EST)

Recharge Connector



www.bainultra.com

Printed in Canada. Copyright © December 2007 BainUltra Inc. All rights reserved. 45220006
Some products, specifications, and services mentioned in this manual are described in pending patent applications or are protected by patents.

Operating the MP3 player

The MP3 player is equipped with a light-emitting diode (LED) screen that indicates the MP3 status:

LED flashing quickly	The MP3 player is trying to synch with a headset.
LED flashing slowly	The MP3 player is synched with a headset.
LED stays lit	The speakers are turned on and the headset is off.
LED is off	The bathtub is off.

Adjusting the volume

Press the "+" key to raise the headset volume or "-" to lower the volume.

Automatic headset shutdown

The headset automatically shuts off when the MP3 player is turned off (i.e., when the bathtub is turned off).

Manual headset shutdown

Hold down the "-" key to turn down the volume. Release and press again until you hear three beeps in the headset.

Recharging headset

Use the provided charger to recharge the headset. Plug the charger into the connector located inside the headset. A two-beep audible signal indicates that the headset is recharging. At the end of the charging cycle, you will hear three beeps. The headset will then shut off automatically.

Do not use headset when recharging.

Using an SD card (not included)

Your system is compatible with MP3 and WMA music formats.

To download relaxing music from a computer, use a portable SD memory card. Insert the SD card into the appropriate reader on your computer.

You may need an SD card adapter for certain computers.

Organizing music

The music must be organized by folder on the card (e.g., by artist or type of music). Only one folder level can be used. The MP3 player will not recognize files if they are filed in more than one folder level.

WARNING: Do not use the headset at temperatures above 45°C.

Optional Accessories

To round out your Euphonia™ system, you can add an SD card to listen to your own musical selections in MP3 or WMA format. You may need an SD card reader to connect the card to your computer.

You will need a 3.5 mm (1/8") male-male jack to connect external audio peripherals.

These accessories are available at electronic supply stores.

1 800 463.2187 

From 8 a.m. to 8 p.m. Monday to Thursday (EST)
From 8 a.m. to 5 p.m. on Friday (EST)

THE BAINULTRA® LIMITED WARRANTY EUPHONIA™: 5 YEARS

LIMITED WARRANTY

This limited warranty is extended only to the original purchaser of the unit under warranty and is valid only when bought through and registered by an authorized BainUltra® retailer. BainUltra® products are designed for residential use only. BainUltra® products used for commercial or display applications will be limited to a two (2) year warranty against defaults in materials and workmanship regardless of the various defective components of the products. BainUltra® products sold outside of North America will be limited to a parts-only warranty through the dealer of the sale. Our service department will help diagnose the problem and will provide parts only for repairs or replacements covered by the warranty. All parts will be shipped to the dealer in North America. BainUltra® will not be responsible for cost of shipping or servicing outside of North America.

The Euphonia system™ offers a warranty on its MP3 player for a five (5) year period, and, on its headset for a one (1) year period, from the original purchase date.

www.bainultra.com

EXCLUSIONS

The above-stated limited warranty applies as long as damage is not caused by an accident, abuse, misuse, fire, insects, use of abrasive products, force majeure or an act of God. Transport, handling or installation damages are also excluded. Any part that must be changed during the warranty period will be covered by the original warranty or for a two-(2) year period following replacement, according to the first contingency.

This warranty is also void if your Euphonia system™ or part thereof has been modified or if any repairs have been attempted by anyone other than BainUltra Inc., an authorized dealer or representative of BainUltra Inc. Any and all components that are not provided by BainUltra Inc., as well as any items attached or installed on your Euphonia system™ after the date of manufacture are expressly excluded from this limited warranty.

The warranty is void if the unit is installed outdoors, or has not been installed in accordance with the manufacturer's instructions and/or in compliance with local codes and ordinances.

1 800 463.2187 

From 8 a.m. to 8 p.m. Monday to Thursday (EST)
From 8 a.m. to 5 p.m. on Friday (EST)