EUT – Battery off View



EUT – Cover off View




Antenna


EUT – Internal View




EUT – Main Board Top View




EUT – Main Board Bottom View




EUT – SAM Board Top View




EUT – SAM Board Bottom View



EUT – Power Manager Board Top View




EUT – Power Manager Board Bottom View




EUT – RF Module View



EUT – RF Module Bottom View



EUT – RF Module Uncovered View



EUT – Battery View

