

# TX-SL013 Serials User Manual

1. Push transmitter	SW1(POWER ON) one time , Light ON
2. Push transmitter	SW2(Hi/Lo speed) one time , Light turn timer Hi or Lo
3. Push transmitter	SW3- (Up) , Light turn up
4. Push transmitter	SW3- (Down) , Light turn down
5. Push transmitter	SW3- (Right) , Light turn Right
6. Push transmitter	SW3- (Left) , Light turn Left

## Specification :

Transmitter Battery : 12V BATTERY

Transmitter operating current : 40 ~ 50mA

Transmitter Battery stands by : 1 year

Frequency : 433.92MHz

Model: TX-SL013

FCC ID. : V78TXSL013

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**IMPORTANT NOTE:** To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.