


# MANUAL FOR ITEM #HW-T0420

## PLEASE READ AND SAVE THESE INSTRUCTIONS :

**Be careful when unpacking the lamp since the wires are connected. If the wires are pulled out of their connectors, the lamp will not turn on.**

1. Place lamp base (C) on soft place.
2. Insert plug (A) into proper power supply.
3. Turn on switch (B) to light bulb (E).
4. You can adjust the shade location by adjusting tube (D).



### Caution:

1. Use only with maximum of 1\*15pcs LED bulbs (included).
2. Burns cool, use less energy and LED's last for over 50,000 hours.

## IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

### FCC NOTE:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This product may cause interference to radio equipment and should not be installed near maritime safety communications equipment of other critical navigation or communication equipment operating between 0.450-30MHz.