

# Wireless Mouse

## Operating and Safety Instructions

### IMPORTANT SAFETY INSTRUCTION

#### READ THE INSTRUCTIONS BEFORE USING THIS PRODUCT

##### NOTICE-- To reduce the risk of product/property damage:

- Do not drop or subject it to strong impacts.
- Do not immerse in water or other liquids.
- Do not attempt to repair this product. Take it to the repair shop of your choice for repair.
- Requires "1x AA" battery (not included)

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.


Changes or modifications to the product not expressly approved by the manufacturer could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Input:1.5V == (1xAA)

Receiver Input:5V == 10mA (xUSB)



### SPECIFICATION

- 2.4GHz Wireless mouse
- USB 2.0
- 26ft working range
- Resolution: 1200DPI
- Supports Windows 10/8/7/XP/Vista; Mac OS
- Battery: 1 x AA (not included)

### HOW TO USE

1. Remove battery compartment cover on the bottom.
2. Take out the USB receiver, insert it into a computer USB port.
3. Insert 1xAA battery into the battery compartment. Make sure the battery is placed with correct polarity.
4. Replace the battery compartment cover.

### BATTERY WARNING

1. Keep batteries away from children.
2. Never throw battery into a fire, as they may explode.
3. Always use the size and type of battery indicated.
4. Insert the battery observing the proper polarity (+/-) as indicated.
5. Clean the battery contacts and those of the device prior to installation.
6. Remove the battery when not using the product for an extended period.
7. Remove spent or discharged battery from the product and dispose/recycle in compliance with all applicable laws.

Mouse: FCC ID: VAC-MPK02-01 USB Dongle: FCC ID: VAC-MPK02-02

All CVS Pharmacy® products  
are satisfaction guaranteed  
or your money back.

Distributed by:  
**CVS Pharmacy, Inc.**  
One CVS Drive  
Woonsocket, RI 02895  
© 2019 CVS Pharmacy  
CVS.com®  
1-800-SHOP CVS  
SKU# 386337  
Made in China  
V-30189