

R/C STURT CAR

FEATURES:


- Full function:
Forward, Reverse, Turns Left & Right.

Battery Requirements:
Vehicle: 4 x "AA"(1.5V) batteries.
Transmitter: 1x9V batteries.

Please read carefully before starting to operate.


1 BATTERY INSTALLATION

TRANSMITTER



VEHICLE

Steering alignment lever
4 AA Batteries



When the steering response becomes erratic, it is usually an indication that batteries in vehicle are getting WEAK and need replacement.

3 MAJOR CAUSES OF VEHICLE MALFUNCTION


- WEAK BATTERIES
- INCORRECT BATTERY INSTALLATION
- INTERFERENCE

CAUTION


- Do not mix old and new batteries
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Batteries are to be inserted with the correct polarity.
- The supply terminals are not to be short-circuited.
- Remove batteries when not in use.
- Please keep this information for future reference.

2 HOW TO OPERATE

TRANSMITTER



VEHICLE



*Check to see that the batteries have been **INSTALLED** in the **CORRECT** position.

- Turn the **VEHICLE** Switch "ON".
- Push **SPEED CONTROL STICK** forward (upwards) to drive **FORWARD**.
- Push **SPEED CONTROL STICK** backwards (downwards) to drive in **REVERSE**.
- Release **SPEED CONTROL STICK** to **NEUTRAL** position to stop the vehicle.

- Don't forget to remove batteries from the vehicle and transmitter when you have finished operating your vehicle.



RADIO INTERFERENCE: Sometimes erratic behavior or loss of control of vehicle is the result of interference caused by high tension wires, high voltage transformers, certain types of buildings, concrete walls or narrow places where **RADIO SIGNALS** sent from your transmitter **MAY BE SCATTERED** thus making it **DIFFICULT** for your vehicle to receive a **GOOD RADIO SIGNAL**. If you encounter this type of behavior or loss of control, **CHANGE TO A DIFFERENT LOCATION**. You will encounter **INTERFERENCE** if **ANOTHER** radio controlled vehicle or **CB radio** is operating in the vicinity on your **SAME FREQUENCY**.

3 OPERATING SAFETY RULES

SAFETY CAUTIONS

- Never give this toy to children under 5 years old.
- After the power of this car is turned on, keep your fingers, hair, and clothes away from the wheels to avoid accidental damage.
- Do not try to catch the car by hand while it is in action.
- Keep the transmitter and the car away from any heat sources, such as electric stoves, gas stoves, or camp stoves.
- Do not play with it in a dangerous place, such as on a road, or on a slope.
- Do not use this car to play with it outdoors in a rainy day.
- Do not play with it on the sand.
- Avoid bumping into any other articles, such as other people or glass, when playing.
- Do not allow children to assemble or disassemble the transmitter or the car by themselves.
- If the car is broken during being used, it should be checked by adult or repaired when necessary by professional technicians before it can be reused.



CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.