

Product: Wireless Doorbell

Model No.:13000

## Operation description

### 1. Function

- A) Both transmitter and receiver are waterproof, available to use outside.
- B) Wireless transfer, avoid destroy wall and save cost.
- C) 16 kinds of sound, silvery and melodize.

### 2. Specification:

#### A) Power:

Receiver: DC 4.5V (3 AA batteries);  
Transmitter: AC 16V.

#### B) Current/power:

Receiver:	quiescent current $\leq 0.8\text{mA}$ ,	work current $\leq 60\text{mA}$
Transmitter:	quiescent power $\leq 2\text{W}$ ,	work power $\leq 10\text{W}$


#### C) Frequency:

Receiver:  $315\text{MHz} \pm 500\text{KHz}$   
Transmitter:  $315\text{MHz} \pm 500\text{KHz}$

### 3. How to mounting

- A) Use screw take down the battery cover of receiver, put 3pcs AA battery in and cover it with the battery cover, then put the receiver where you want to put.
- B) Take down the transmitter back housing, then connect to AC 16V power, then put the transmitter where you want to put
- C) Make sure neither receiver nor transmitter close to the metal, otherwise will affect the performance.
- D) Make sure the way of connect is correct before use it.

### 4. Transmitter connect way:



### 5. Accessory:

1. M3\*25 screw:3pcs.
2. waterproof gasket:1pcs.
3. Double tape:1pcs

REV1.0