

INCLUDE

OPERATION:

1.OPEN THE CAR BOTTOM SWITCH;(STIR TO"ON" POSITION). 2.TURN TO CONTROL FROM A DISTANCE TO MANIPULATE A POLE TO DIRECT THE CAR TO MOVE.

NOTES:

1.IF THE CAR BECOMES SOON SLOWLY, IT'S NOT EASY ERECTION RUN ABOUT, WOULD BE ELECTRIC POWER SHORTAGE NEED TO BE REFRESH.
2.MUST TURN OFF THE POWER SWITCH OF THE CAR BOTTOM WHILE DONT PLAY, OTHERWISE, THE ELECTRICITY QUANTITY OF THE BATTERY IS VERY QUICK EXHAUSTION .

1.GO FORWARD



2.RETREAT



3.TURN TO THE LEFT



4.TURN TO THE RIGHT



5.SITU ROTATION



6.VERTICAL ROTATION



7.ROLLING FORWARD



MUTATE



MADE IN CHINA


THE BATTERY USAGE REGULATION

- 1.The remote control uses 9 V layer battery, using a set of 4.8 Vs on the car can refresh pond;
- 2.Install or replace battery please watch for a pole;
- 3.Refresh the battery can serve as guardian at the adult when refresh, refresh time is about 4-6 hours;
- 4.Refreshing battery not can't refresh;
- 5.Can't mix battery of use the lately old or different type;
- 6.Connect the line's carry shouldn't be short-circuited.

WARN:

This article may imply small spare parts please don't let the children under three years of age play this article contains the electronics component, can not go into water or under the damp environment usage please don't break control from a distance antenna,so that in order to prevent results in injury.

Changes or modifications not expressly approved by the party responsible for compliance could void the use's authority to operate the equipment.



REFRESH:

1.Insert the charger indoor 220/110 V AC power electric outlets;
2.The charger outputs the exportation plug of the line bitter end to insert to refresh battery to refresh electric outlet;

ATTENTION:

1.Have to use the 4.8 V type appropriation that our company install to refresh an electric appliances to refresh, use the other charger of the not clear characteristic refreshes to damage battery probably;
2.Refresh time should not lead too long, be good enough to make the battery is saturated for 6 hours, refreshing excessively will shorten the service life of the battery, or even cause the battery deformation

BATTERY INSTALL

- 1.Push down lightly to remove the battery cover on the back of the remote controller.
- 2.Cover the battery cover again after inserting the 9V alkaline battery.

