

立体声 蓝牙耳机

Bluetooth® Stereo Headset

用户使用说明书 USER GUIDE

使用入门

■ 耳机由以下部分组成:

- 1.多功能键()
- 2.麦克风()
- 3.充电插孔(- C +)
- 4.扬声器()
- 5.耳挂()
- 6.指示灯()
- 7.上一曲/音量-()
- 8.下一曲/音量+()

■ 充电器和电池


使用充电器给本耳机充电前,请先检查充电器是否为耳机配套充电器。

警告: 必须使用配套的充电器给耳机充电,使用不配套的充电器可能会损坏耳机。

耳机充电

本耳机使用内置式不可拆卸充电电池,请勿尝试从耳机中取出电池,以免损坏耳机。

1.充电时,先将耳机关机



- 2.将充电器插头插入耳机充电接口(- C +),另一端插到交流电源插座上(如图)。此时耳机开始充电,充电时,红灯()恒亮。
- 3.耳机充足电,大约需要2-3个小时,充满后蓝灯()恒亮或红灯熄灭。

1

开机关机

开启耳机时,请按住多功能键(),耳机蜂鸣且蓝色指示灯()会快速闪烁或长按多功能键()进入配对状态。

关闭耳机时,请按住多功能键(),耳机蜂鸣且蓝色指示灯()会快速闪烁两下。

蓝牙配对步骤:

- 1.配对时,请将蓝牙耳机和手机的距离控制在1米范围内,越近越好。
- 2.确保蓝牙耳机处于开机关状态。
- 3.按多功能键(),到蓝灯()恒亮或红蓝灯()同时(交替)亮,此时耳机进入蓝牙配对状态。
- 4.按照蓝牙手机的说明书,打开“蓝牙搜索”或“添加新设备”选择耳机名称,确认后按手机的提示输入“0000”确认。注意:蓝牙耳机的配对时间是有限的“一般为60秒”,如果蓝灯()熄灭或为红灯()闪烁状态说明蓝牙配对状态已停止,如果您这时仍未配对成功,请重复步骤1-4再次配对。

断开耳机与手机的连接

要断开耳机与手机的连接(例如,将手机连接至其他蓝牙设备),请采用以下任一方式:

- 關閉耳機
- 使用手機的“藍牙”功能表斷開耳機與手機的連接。
- 將耳機移至距離手機10米(約30英尺)以遠的位置。

将已配对耳机重新连接至手机

要连接耳机和手机,请打开耳机,使用手机的“蓝牙”功能表建立连接,或按一下多功能键()。

2

您可以设置手机,使其在耳机启动时自动与耳机建立连接。在手机中,要实现这一目的,请在“蓝牙”功能表中更改配对设备设置。

接听来电

来电话时,耳机内发出来电提示音或铃声,按下耳机多功能键(),即可接听来电,或使用手机接听键,接听来电。

挂断通话

按下耳机多功能键()或使用手机挂断键即可挂断通话。

拒绝来电

长按2秒耳机多功能键()或直接用手机挂断键即可拒绝来电。

暂停或保留通话

通话时,长按多功能键()2秒可保留现有通话,如需恢复通话,则长按多功能键()2秒。(是否支持本功能,取决于手机)

末位重拨

耳机支持末位重拨功能:长按2秒耳机多功能键()即可实现末位重拨。

音乐播放/暂停/选曲

收听音乐时可以操作多功能键()播放或暂停,上一曲、下一曲进行选曲等。(短按一次“+”为下一曲,短按一次“-”为上一曲)

音量调节

音量键调节音量的大小:长按住“+”3秒为音量增大,长按住“-”3秒为音量减小(注:当音量达到最大或最小时会有蜂鸣音提示)

3

Product overview


The Bluetooth Stereo Headset is composed of:

- 1.MF Button ()
- 2.Microphone()
- 3.Charging Jack(- C +)
- 4.Speaker()
- 5.Earhook()
- 6.Indicator Light()
- 7.Previous Song/Volume (-) Button()
- 8.Next Song/Volume (+) Button()

Charging the headset

Your headset uses a rechargeable battery. You must charge the battery fully before using the headset for the first time. Please make sure to turn off the headset before charging.

1. Plugging the charging cradle in the port.



2. The red indicator light remains solid when charging.
3. The fully charging takes approximately 2-3 hours.
4. The indicator light is in solid blue when charging completed.

How to turn on/off:

Turn on: Press the MF button until you hear the beep and the blue indicator light flashes.

Turn off: Press the MF button until you hear the beep and the blue indicator light flashes twice.

4

Pairing with your Bluetooth phone

1. The distance between the Bluetooth headset and your Bluetooth phone would be better within 1 meter when pairing, the closer the better.
2. Ensuring the headset is off.
3. Pressing still the Multifunctional Button until you see the blue light remains solid.
4. Set your Bluetooth phone to discover the headset by following your phone's guide. Typically, the steps involved are going to a “Setup” “Connect” or “Bluetooth” menu on your phone and then select the option to discover Bluetooth devices.
5. Your phone will find the headset and ask if you want to pair with it. Confirming this by pressing “yes” or “ok”.
6. Enter passkey “0000”, then press “yes” or “ok”.

IMPORTANT: If pairing is successful, the indicator light will flash in blue 10 times rapidly before going to flashing every 3 seconds, if unsuccessful, the light remains on, and you will need to reattempt the pairing. While the light will go out if the pairing time takes more than 60 seconds, in that case, you need to turn off the headset and turn it on for pairing again.

Disconnect the headset from the mobile phone

If you want to disconnect the headset from the mobile phone, you can do as below:

- Turn off the headset
- Disconnect the headset from the Bluetooth list the mobile

5

phone.

• Take the headset away from the mobile phone for more than 10 meters (33ft).

Reconnect the paired headset with the mobile phone

If you want to connect the paired headset with the mobile phone, you can do as below:

- Turning on the headset and setting up the connection in the Bluetooth list of your mobile phone
- Pressing once the MF button of the headset. (You have to do the setting in your mobile phone to allow the automatic connection with the paired headset.)

Answering a call

When you hear the ring tone, press the MF button once. If you prefer answering the call by your phone, you can transfer the call from the headset on your phone.

Ending a call

Press and release the MF button once or end call on your phone's keypad.

Answering or rejecting a call when listening to music

If there is ring tone of incoming call when you are listening to music from your phone or PC or other Bluetooth enabled

6

devices, press the MF button to answer the call and press and hold the MF button for 2 seconds to reject the call.

Pause or put a call on hold

During the phone call, just press and hold the MF button for 2 seconds to put a call on hold. If you want to resume the call, you can also press and hold the MF button for 2 seconds. (This is subject to the mobile phone's feature.)

Redialing the previous call

Press and hold the MF button for 2 seconds until you hear a long beep.

Playing music

When you are listening to the music, you can press the MF button to play music or make a pause and the volume control buttons to select previous song and next song (Briefly press the Volume + to go to next song and Volume - to go to the previous song.).

Volume control

Press and hold the Volume Control (+) to increase volume and release when it reaches your preferred volume. Vice versa!

7

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: VO-I4S

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.