

6+



© 2012 EyeSpy TM is a registered trademark of EyeSpy Toys Ltd. All rights reserved.
Manufactured for and distributed by Citiwell International Inc.
Conforms to the safety Requirements of ASTM F963 and EN-71(1).
WARNING! . Not suitable for children under 3 years of age due to small parts.
In an effort to continually improve our products, the items inside this package may vary slightly
from the photographs

9-401 Magnetic Drive, Toronto, Canada, M3J 3H9
Customer Care: 1866 469 9686

MADE IN CHINA
PRINTED IN CHINA

www.eyespytoys.com

DeeBee®




Contains LiPo battery pack. • Battery pack must be recycled or disposed of properly. • If at any time in the future you should need to dispose of this product please note that Waste Electrical Products should NOT be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. (Waste Electrical and Electronic Equipment Directive).

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.



LINK

SURVEILLANCE TECHNOLOGY

INSTRUCTION GUIDE

www.eyespytoys.com



WARNING:
CHOKING HAZARD – Small parts. Not for
children under 3 years.

DeeBee®

TROUBLE-SHOOTING

The EyeSpy™ Linx is an advanced walkie-talkie system featuring voice communication and two-way color video communication, coupled with the ability to send and receive pre-programmed phrases and emoticons.

KEY FEATURES

Linx:

- The Linx is a live video Walkie Talkie operating in true color and night vision modes. It sends video and sound signals to another Linx device at a range of up to 500 feet (152 metres) in open areas, away from devices that can cause electrical interference. It also allows the user to send preset icons and messages to the other Linx device.

USB Cord :

- The USB cord is used to charge the Linx's lithium-polymer rechargeable battery, and connects the Linx to the USB port that is commonly found on most computers.

Earpiece:

- The earpiece consists of a built in microphone and speaker. One connects to each Linx handset and enables the users to speak to each other. The built in volume control allows the user to set the volume to a comfortable level.

If at any time the Linx unit stops working, or works in an unexpected fashion:


1. Check the battery condition icon on the viewing screen. If indicated remaining life is low, please recharge the unit with the USB cord.
2. To reset the unit, switch 'OFF', wait for 30 seconds, then switch "ON" again.

For any other problems or concerns, please contact us via the EyeSpy website www.eyespytoys.com or call our **Customer Assistance Line at 1866 469 9686**

CONTENTS LIST AND PARTS IDENTIFICATION



Linx x2




Earpiece x2




USB Cable

7. The “down-arrow” button under the right side of the screen is used to display six pre-loaded phrases. Choose the phrase you wish to send and press the orange SEND button to send the phrase to the other Linx unit. If you do not send an icon or phrase in five seconds the screen will revert to a normal image.



Messages

8. The screen image will darken slightly after about 30 seconds to preserve battery power. Touching the left “up-arrow” will bring up the brightness again.



"Low battery" indicated


9. The blue CALL button is pressed to let the other user know you want to communicate. Both units must be on. When the CALL button is pressed the word CALL-ING flashes on both screens and a tone is heard in the headphone. When the second user answers by pressing their CALL button the word CALLING will stop flashing. Pressing CALL again will eliminate the word.

10. When the screen is on a blue battery icon appears in the upper right corner. A solid blue icon shows that the battery is fully charged. As the power is used a ring will disappear. After more use a second ring vanishes. At this point, with only one ring showing, the available usage time is limited. When the battery needs charging the screen will go black.

Never point the Linx camera at a very strong light source such as the sun, a nearby floodlight or car headlight or a powerful flashlight. This may destroy the camera and screen. If this occurs, you should return the unit to us for repair or replacement at your expense.

1. Both Linx units contain a Lithium-Polymer rechargeable 800mAh, 3.7V, non-removable Battery. These batteries need to be charged before the units can be used.


2. To charge a unit, plug the large end of the included USB cord to the USB jack on a computer or standard USB hub. Then plug the small end of the cord into the mini USB port on the right side of the Linx. The screen will light up and the EyeSpy logo will be seen. Let the Linx charge for three hours. Repeat the operation for the second Linx unit.



IMPORTANT SAFETY INSTRUCTIONS AND WARNINGS For LI-ION / POLYMER BATTERIES

- You must read these safety instructions and warnings before using or charging your battery.
- Never disassemble the Linx or try to remove the battery.
- While generally safe, Lithium-Polymer batteries are volatile. Failure to read and follow the below instructions may result in fire, personal injury and damage to property if charged or used improperly.
- Lithium-Polymer battery may explode and cause fire if misused or defective.
- When charging the battery, please place it on a fire resistant surface. Do not leave the Linx on a wood surface or on paper, carpet, or grass. Do not leave the unit unattended while it is charging. If at any time you witness the Linx starting to swell up, emit smoke or feel hot, discontinue charging process immediately, disconnect the Linx and observe it in a safe place for approximately 15 minutes. The battery may be leaking, and the reaction with air may cause the chemicals to ignite, resulting in fire. In the unlikely event of this occurring, please contact us via the EyeSpy website www.eyespytoys.com or call our Customer Assistance Line at 1866 469 9686.
- Never store or charge the Linx inside your car in extremely warm temperatures (105°F or 41°C), since extreme temperature could ignite a fire.
- Never drop the Linx, as this may cause a battery to leak.

HOW TO USE




A NOTE ON TRANSMISSION AND RECEPTION RANGE:

- EyeSpy wireless transmission can suffer from interference caused by other 2.4MHz devices such as baby monitors, home wireless CCTV security systems, wireless telephones and WIFI.
- Keep away from high voltage cable and towers. Keep away from communication/mobile stations. Do not use the units in damp, wet or high temperature conditions.
- The screen quality is severely impaired by sunlight
- The maximum effective range of 500 feet (152 metres) may be severely reduced if the units are used in any of the above noted situations.
- Reception is good in open areas such as arenas, or outdoors on level ground and away from buildings and transmission towers, poles and wires. Keep a good distance away from home or business Wi-Fi routers. Keep away from machine rooms.


3.

HOW TO USE

1. Plug one earphone/microphone unit (two included) into each Linx unit. Insert the plug into the round jack on the right side of each Linx. The earphone/microphone unit can be adjusted for use on either a left or right ear. The curved "over-the-ear" unit can slide off the main unit section and then be re-attached on the opposite side. Unlike other walkie talkies, the linx is unique in that it allows for 2 way talking as in a conversation on a telephone.




2. Turn each unit on by pressing in on the POWER button and hold it in for two or three seconds, just until the EyeSpy logo appears on the screen.



3. Give a Linx unit to a nearby person and keep one for yourself. Hold the Linx about a foot away from your face with the screen aimed toward you. Tell the other person to hold their Linx the same way.

4. Press and release the black "up-arrow" button under the left side of the screen to see either your face or your partner's face. This can also be used as a "mirror" and also to position yourself on the screen so that the other person can see you in frame.

5. Press and release the black "down-arrow" button to turn on the green-tinged "night-vision" feature. Press and release again to turn the screen black. Press and release again to return to a normal picture.



Icons

(Continued on page 5)

4.