


16. ANTENNA LOCATIONS AND SEPARATION DISTANCES

16.1. SUMMARY OF SAR TEST CONFIGURATIONS

Configuration	Antenna-to-User distance	SAR Require	Comments
Lap-held	185 mm From Main-to-user	Yes	


16.2. ANTENNA-TO-USERS

Lap-held configuration
(Separation distance between antenna and user)



17. SETUP PHOTOS

Lap-held, 0 mm from the bottom of the laptop base-to-phantom



18. HOST DEVICE PHOTO



END OF REPORT