

# User guide

## 1.1. Description:


This product is a Bluetooth wireless optical mouse, dedicated, PS3 and PC host, the host of three key (Left key/Middle key/Right key) with the wheel.

This product incorporates a separate baseband processors and integrated 2.4GHz transceiver, Bluetooth 2.0. Use 2.4 G wireless data communication with PS3 console(or bluetooth adapter).Wireless module frequency coverage: 2402-2480MHz, Channel: 79, data modulation mode: FSK. Antenna type: IFA, Antenna gain: 3.3dBi (Max) .

. The wireless distance may amount to 8-10 mete.

## 1.2. Use method:

### 1.2.1 Install the battery: (using the battery: 2 AAA batteries-1.5V) (picture 1)




Press and hold the battery cover, remove the battery cover, according to a diagram position packed battery, the battery cover on the cover (picture 2/3).

### 1.2.2 The mouse on the PS3 for use on the host:

#### 1.2.2.1 PS3 controller and PS3 host (picture 4) line

The PS3 host and TV link good, adjust the TV video. in accordance with the PS3 host switch 级 machine press-on, led indicates a green; use PS3 controller (picture 5) control, set the PS3 controller USB cord and PS3 host connections, by PS PS3 controller keys. using boot PS3 master operations.



picture 4



picture 5

#### 1.2.2.2 Enter the PS3 host Bluetooth option (picture 6/7):




picture 6



picture 7


### 1.2.2.3 PS3 host and mouse wireless connect:

The Mouse bottom side up (picture 8), the power switch to "ON" position, press the Pairing KEY, through the lens to see the Green led is blinking.



picture 8

Starting the blue tooth in HOST searches the machine, searching the blue tooth in perimeter in HOST in machine equip; choose the " connect" operation after searching the Bluetooth Mouse( picture 9).Moving the rat mark can operate;




picture 9

### 1.2.3 Use the mouse to the computer:

Choose comes with Bluetooth computer,through the "start",  $\Rightarrow$  "Control Panel"  $\Rightarrow$  "Control Panel"  $\Rightarrow$  "Bluetooth device", see the dialog box -selection dialog box to add ","

Select "find"  $\Rightarrow$  selected "next step" , at this point in the Mouse on the picture by Pairing KEY (8), Search to "Bluetooth Mouse", select "next",  $\Rightarrow$  "the picture does not use the password ", select" next " Display the "new devices can use the" selected "when completed" .

With the computer connect after completing, can use on the computer.( picture 10)



picture 10

FCC NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.