

Circuit Description

Fuse: When input is shorted, it performs input shorted protect function.

L1, C1: Work together with to performs EMI function.

D1, D2, D3, D4: Performs rectification function.

Q1, Q2: Performs Oscillating function, let low frequency switch high frequency.

L2, C5, C6, C7: When switching power, the L2 and C7 take place series resonance startup the lamp, then L2 restricting current.