

### 1. Installation Steps:

Step 1: Plug the receiver into the computer's USB interface, the computer will automatically install new hardware drivers;

Step 2: Wait for the computer prompts for new hardware drivers installed;

Step 3: And the corresponding receivers can be used in conjunction with the keyboard or mouse.

Note: If step 2 new hardware driver is installed, the computer prompted to restart, please restart the computer.

2. Applicable models: IBM PC/AT Compatible, Compatible Windows 98/2000/XP/VISTA/Windows7

## Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.