

TX3 QUICKSTART
PERFORMANCE MODE

Preset Back: (Preset Forward:)

EDIT MODE

Effect/FM/Amp Down: (Effect/FM/Amp Up:)

Effect/FM Value Up: (Effect/FM/Value Down:)

STORING A PRESET

When you have created a sound that you would like to store in memory as a new preset. Press both () until the display blinks. Use each () to select the desired location for your new preset. Once you have found the location hold both () until **ST** appears. You have now stored a new preset.

TUNER MODE

Hold both () until **tu** appears. You are now in tuner mode.

FM Jam
Cardiff, CA USA

www.fm-jam.com

FCC ID: VYHTX3-18 PATENT PENDING

MADE IN THE U.S.A.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.