


AT2009 Transmitter Instruction



AT2009 Transmitter

This is a transmitter which is used to control window curtain up and down in the house.

【FUNCTION】

- Up Stop Down

Transmit signals of: " up " , " stop " , " down "

- SELECTION

Change transmit channel (cannot transmit directly)

- CHANNEL SETTING

Set transmit and receive channel study

【OPERATION】

1,Press "up" button ,The transmitter send a signal to receiver
for operating a up motion.

2,Press "down" button ,The transmitter send a signal to receiver
for operating a down motion.

3,When the receiver is moving as up or down, press the "stop" button,

The motion will be stop.

4,The transmitter have 6 channels, press “selection” button, and see the 6 LED light , which LED light means which channel have been selected.

5,Channel setting button only the receiver have been set. it is can be useful. When press this button, the receiver will study and record the transmitter's code.

FCC ID Label Sample for FCC ID: VZ5AT2009

FCC ID: VZ5AT2009

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and**
- (2) this device must accept any interference received,**
including interference that may cause undesired operation.

NOTE : THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT . SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.