PC-MAX Block

PC-MAX

Car

Car Interface
PCMAX Car Interface

Car Interface

PWM/VPW
PCMAX PWM/VPW

PWM/VPW_RX

Car Interface

CAN
PCMAX CAN

CAN_DATA

Car Interface

KLine
PCMAX KLine

CPLD_DATA
Car Interface
RX Select

RX Select
PCMAX RX Select

RX Select

Car Interface

MCU
PCMAX MCU

PWM/VPW_RX

CAN_DATA

PC_DATA
CPLD_DATA

Inside

36MHz

BlueTooth Interface
PCMAX BT Interface

Inside

BlueTooth
16MHz

Wireless

BT_ENABLE_BLOCK
PCMAX BT_ENABLE_BLOCK

BlueTooth
BT_EN
BT_DATA

Communicate Select
PCMAX Communicate Select

BT_DATA
PC_DATA
USB

USB to UART Interface
PCMAX USB to UART

USB   BT_EN

Inside

6MHz   **USB**

PC

**Description：**

   The communication between PC-MAX and PC can be wired(by USB) or wireless.The wireless communication will be unable

when the wired communication is working,or will be able.