

FM Transmitter User Guide

1. Plug into 3.5mm jack of your personal media player. (MP3, iPod, Radio..etc.)
2. Turn on the power button on the right hand side of transmitter.
3. Make sure your media player is powered on, and then press Scan button on transmitter (the same one as power button).
4. You can switch the channel by pressing scan button on transmitter.
5. Make sure your headset receiver is on the same channel as transmitter.
6. Then the transmitter will transit music automatically to your headset.

FCC NOTE:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and;
2. This device must accept any interference received, including interference that may cause undesired operation.