

MC-D01 User Manual

1. After install the battery on the receiver , it will flash 30 seconds; if the receiver receive a singal from remote during this 30 seconds., it will stop flashing
2. Press LOCATE button , the LED on the receiver will flash 10 seconds, if press the LOCATE again during this 10 seconds, the LED will stop flashing
3. Press CLIMB button, the light on the receiver will turn on, if press again, the light will turn off.
4. Press FLASH button, the LED on the remote will turn on and release the button, the light will turn off.

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for and radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.