

Forword

Thanks very much for using VIG Mini digital vidicon. The book gives detailed introductions about the functions of this machine in hopes of you enjoying it . Please read this book carefully before using it.

Attention

1. This machine is high-precise electronic product, please don't take it apart by yourself, and also please don't make any changes on any parts, which results in be out of warranty.
2. Please don't bump, throw this machine heavily .
3. Please don't put this machine in following conditions: high temperature, damp, dusty, strong magnetic, and long-time shining in the sun.
4. Clean the shell of this machine with a dried damp cloth , it's not allowed to clean this machine with any impregnants .
5. This machine must avoid water.
6. Please select suitable volume when you listen so that listening ability is not damaged.
7. Please use battery, charger and accessories permitted by manufacturer, using any other model products will break the warranty regulation and may cause dangers.
8. Please deal with the abandoned machine and accessories.
9. If you have any questions in use, please contact our service center .

Announcement

1. Please take care of your warranty materials , our company is not responsible for the losing due to the materials' missing.
2. This instruction is made as per the original edition, please refer to the disc or instruction book along with machine when the machine is upgraded .
3. Photos in the instruction is ONLY for reference, product is subject to the goods.
4. This machine can be widely used during office staff, teachers, students, business negotiations, recording athlete sporting, sneaking visit and attaining evidence, but it's prohibited to be in illegal use such as candid snapshot.and we are not responsible for illegal actions.

Contents

Product introduction

1. Brief product introduction and specification
2. Accessories along with machine
3. The lowest working requirements
4. Connect with computer

Introduction of function key and function light(model shift operation)

1. Press key/insert key function(including model shift)
 - (1) MP3 up and down model
 - (2) Volume model
 - (3) Picture-taking, video, record model
2. Function lights
3. Power

Operation instruction

Stock disc

USB security pick-out

Storm.exe software installation and use

1.installation

2. use

Product introduction

1. Brief product introduction&Specification

1): "VIG Mini" is a multi-functional,energy-saving and the minimum digital vidicon in the world, it's convenient to be brought and integrate with picture-taking, video,recording,MP3,"U" disk,disk-reading .

2):Dimension : L*W*H=48*30*13.5 Weight: 39g

3):High Clear Picture-taking with pixels of 3 million.

4):Video file: 640*480 resolution Picture-taking file: 1024*1280 resolution 22 frame/s

5):Video format: AVI, player recommended: storm

6):High-sensitive Microphone can record voice with 64 sqm clearly and play without any cacophony.

7):High-quality MP3 play with stereo

8):Inner stock is 1GB(can extend to 8GB) which can record over 3 hours.

9):Built-in high-volume polymer Li-battery can video for 90minutes, and charge continuously with equipment along with the machine.

10):USB2.0 standard access without drive and out power

11):Suitable for any computer and other electronic equipments with USB access.

12):Fast data reading speed: 900k/700k bit/s(relevant to main machine speed)

13):Support XP/MAS OS/LINUX/VISTER,recognize operation system automatically and install relevant drive program, no need by manual.

14):MP3 music format support MP3/MIDI/WMA/WAV/AAC

This handbook will explain that in detail miniature digital camera each function the use way, invites your careful reading.

2. Accessories along with machine

This machine includes following accessories:

>Earphone (one set)

>Charger(one pc)

>USB wire(one pc)

>Hanging line(one pc)

>Disk(one pc)

>Acceptance certificate (one pc)

>Warranty card (one pc)


3. Lowest computer working requirements

- Microsoft 98/2000/ME/XP/MAC
- USB access
- CD-ROM drive
- 40MB hard disk
- 256MB internal stock

4. Connect with computer

Please use accessories along with the machine or 5P USB line as the media between this machine and computer, insert the square USB line end into the machine's USB access,then insert the rectangle USB line end into the computer's USB access.

Function Key instruction



VIG-800 Unpower-off Mini Vidicon+ MP3 Operation Instruction

Outer adaptor needed file would display an tomatillo

USB Connector

In case of data lost when VIG-800 withdrew form. USB port, please double cock Hand nurse and

Pull out the USB step by step according to reminder remark: If computer could not detect CD when USB and connected to computer directly.

storm software settlements se:

use attached CD and dick storm

FCC ID:W8LVIG-800

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.