

Figure 7

Inside Configuration of the EUT

**Figure 8**

Inside Configuration of the EUT




Figure 9

Inside Configuration of the EUT




Figure 10

Inside Configuration of the EUT



Figure 11

Inside Configuration of the EUT



Figure 12

Inside Configuration of the EUT



Figure 13

Inside Configuration of the EUT

**Figure 14**

Components Side of the PCB




Figure 15

Components Side of the PCB




Figure 16

Components Side of the PCB




Figure 17

Components Side of the PCB




Figure 18

Remote Control Line

