



ProDealer Buttons

Users Manual and Guide

The TDPro Dealer Buttons are a must have for any Texas Hold'em game!

This product is great for a casual home game or a large Texas Hold'em Tournament. The ProDealer Buttons functions as a dealer button, a timer, visual alerts, and more importantly a unification device for table management and multi-table synchronization. The buttons can be programmed easily with no limitations. Multiple alarm statuses indicate to all players that an adhered event has or will occur. The product will allow for a faster and more professional game setting. The ProDealer Buttons are slightly larger than a normal dealer button but can fit easily fit into most standard poker chip cases. The ProDealer Buttons comes packaged with instructions. Batteries are NOT included. Four AAA Alkaline Batteries or Rechargeable Batteries may be used. Batteries should be removed when not in use.

The ProDealer Buttons are a high quality, adequately sized, computing devices with built in digital timers, visual lights, and wireless communications. ProDealer Buttons are made of the highest quality plastic and weighted to ensure easy sliding across any poker table. They featured tamper proof design, ergonomically integrated control buttons on top, a USB connection to its integrated website (www.ProDealerButtons.com) allowing for downloading unlimited game settings. ProDealer Buttons allows everything from putting players on the clock, providing simultaneous warnings to players on hundreds of tables that in "x" seconds the blinds will be increasing, as well as synchronizing multi-games on multi-tables when used with other ProDealer Buttons. The buttons have visual alerts, laser scripted lettering, manual on/off, 24 hour auto-off, low battery indicator. They are approximately 3.1" in diameter and 0.65" thick.

Disclaimer:

The material in this users guide is for informational purposes only. The product(s) it describes are subject to change without prior notice, due to the manufacturer's continuous development program.

User Instructions:

Congratulations on the purchase of your ProDealer Button(s).

Now that you have opened the packaging, you are required to insert the batteries into the product in order to power the unit(s).

Inserting the batteries:

1. Each button requires 4 AAA batteries
2. Remove the battery cover which is the bottom of the button case





- a. Insert fingers into the slots and turn counter clockwise to open, clockwise to close
3. Insert the batteries as shown / depicted in the battery slots
4. On the Small and Big Blind buttons the LED indicators will begin flashing yellow, green, & red
5. The Dealer Button will need to be powered on for all buttons to properly synchronize

Powering the Dealer Button:

The ProDealer product come loaded with a “Is this working default template” in order for you to ensure the buttons are working correctly and efficiently; however, it is very important to note that this will not be the template you will utilize for ordinary game play.

1. Locate the button marked “Dealer Button” and press the button on the left one time
2. You will see the LED indicators flash yellow, green and red
3. You will see the words “Welcome Dealer” now displayed on the Dealer Button screen
4. On the “Dealer Button” now press the button on the right one time to synchronize all buttons
5. All buttons will now synchronize and the LED indicators will all be flashing red
 - a. Dealer Button will display the Round, Time, Big Blind amount, & Small Blind amount
 - b. Big Blind Button will display the amount of the Big Blind
 - c. Small Blind Button will display the amount of the Small Blind
 - d. Other Dealer Buttons if being used for multi-table play will display the Round, Time, Big Blind amount, & Small Blind amount
 - i. Note: the Pause/Reset control buttons on these “Dealer Buttons” will be disabled while being controlled from the “Master Dealer Button – Step 3 above”
6. On the “Dealer Button” now press the button on the right once again in order start timed play
7. If the game needs to pause, please press the button on the right once again
8. When the game should resume, please press the button on the right again

Preparing for a real game:

1. Using a internet capable computer go to the website www.ProDealerButtons.com
2. Choose the option “Templates” for Tournament Play
3. The first time you will be asked to fill out the appropriate answers to register your product
4. Plug the USB cable into the Dealer Button and the internet capable computers USB Port
5. Enter in your game information by answering the appropriate questions
6. Click the Save and Submit Button
7. Congratulations, you are now ready to begin

Frequently Asked Questions:

Q. How far can the buttons transmit and receive information?

A. The buttons are rated to transmit and receive information at more than a 600’.

Q. How long will typical battery life be on the product(s)?

A. New or fully recharged batteries should last more than 16 hours of continuous use.





Q. Can I use rechargeable batteries?

A. Yes, rechargeable and regular batteries can be used.

Q. How can I skip through rounds?

A. Hold down on the Pause/Reset button until the Round number appears on the screen, then press the On/Off button advancing the Round number until you reach the desired round to start or restart at.

Q. Is there a slow play timer?

A. Yes, by pressing and holding down the On/Off and Pause/Reset buttons at the same time will invoke the slow play clock set for 1 minute.

Q. How do I power off my units?

A. Press and hold down on the On/Off button will power off the Dealer button. The blind buttons will power down when their Dealer button powers off.

Q. Can I program my own advertisements?

A. You can contract with www.ProDealerButtons.com if you wish to advertise on your buttons and/or to other ProDealer Buttons.

Care and Maintenance of the buttons:

- Keep the unit clean. Clean it with a moist water solution. Dry it carefully with a soft towel
- Do not clean with alcohol or abrasive material such as steel wool or cleaning chemicals
- Store the unit in a cool dry place
- Do not store in a damp environment / non-breathable material (i.e., plastic or damp gym bag)
- Do not store the unit with conductive material such as a wet towel
- Do not store or use the buttons around strong magnets.
- Keep the unit out of the extreme cold or heat.
- Do not expose to direct sunlight for long periods of time, such as leaving it in a car because the buttons can warp and / or the displays could lose luminosity.
- The first sign that the battery may be running down is when the display indicates low battery message.
- Unauthorized accessing or servicing any internal parts of any button can cause damage and will nullify any warranties on the button(s).

TD Pro's Limited Guarantee:

This limited ProDealer Button guarantee is issued by TDPro LLC for the consumers who have purchased this product from an authorized seller.

TDPro LLC guarantees to the original consumer of this product that the product will be free from defects in material or workmanship for 90 days from the date of purchase.





Please keep the receipt of purchase, which is your proof of purchase.

The guarantee does not cover the batteries, damage due to misuse, abuse, accidents or non compliance with the precautions; improper maintenance, commercial use, cracked or broken cases.

The guarantee does not cover any damages, losses, costs or expenses, direct, indirect or incidental, consequential or special, arising out of, or related to the product. During the guarantee period the product will be either repaired or replaced at an authorized service center free of charge.

This guarantee does not affect the consumer's statutory rights under applicable national or state laws in force, or the consumer's rights against the dealer arising from their sales / purchase contract.

Privacy:

This Privacy Statement has been prepared by TDPro, LLC, the host and operator of ProDealer Buttons. TDPro, LLC operates a variety of web sites ("Web Site" or "Site") including www.ProDealerButtons.com and www.TDPRO.com and is committed to protecting the privacy of our Web Site users ("Users") and Dealer Buttons members ("Members"). To that end, we offer this Privacy Policy to inform our Members and Users (referred to individually, or collectively, as "you") of how we collect, use and disclose your personal information.

TDPro, LLC will take reasonable steps to protect your personal information in accordance with this Privacy Policy and applicable laws. To make this notice easy to find, we provide a link to our policy at the bottom of most pages of our Web Site.

Privacy Notice Table Of Contents:

1. Our Commitment To Privacy
2. The Information We Collect
3. How We Use Information
4. Our Commitment To Data Security
5. Our Commitment To Children's Privacy
6. How To Access Or Correct Your Information
7. How To Contact Us

Our Commitment to Privacy

Your privacy is important to us. To better protect your privacy we provide this notice explaining our online information practices and the choices you can make about the way your information is collected and used. To make this notice easy to find, we make it available on our homepage and at every point where personally identifiable information may be requested.





The Information We Collect:

This notice applies to all information collected or submitted on the ProDealer Buttons and TDPro websites. On some pages, you can order products, make requests, and register products and to receive materials. The types of personal information collected at these pages are:

1. Name
2. Address
3. Email address
4. Phone number
5. Credit/Debit Card Information
6. (etc.)

On some pages, you can submit information about other people. For example, if you order a gift online and want it sent directly to the recipient, you will need to submit the recipient's address. In this circumstance, the types of personal information collected are:

1. Name
2. Address
3. Phone Number
4. (etc.)

The Way We Use Information:

We use the information you provide about yourself when placing an order only to complete that order. We do not share this information with outside parties except to the extent necessary to complete that order. We use the information you provide about someone else when placing an order only to ship the product and to confirm delivery. We do not share this information with outside parties except to the extent necessary to complete that order. We offer gift-certificates by which you can personalize a product you order for another person. Information you provide to us to create a gift-certificate is only used for that purpose, and it is only disclosed to the person receiving the gift. We use return email addresses to answer the email we receive. Such addresses are not used for any other purpose and are not shared with outside parties. You can register with our websites if you would like to receive our catalog as well as updates on our new products and services. Information you submit on our websites will not be used for this purpose unless you fill out the registration form. We use non-identifying and aggregate information to better design our websites and to share with advertisers. For example, we may tell an advertiser that X number of individuals visited a certain area on our websites, or that Y number of men and Z number of women filled out our registration form, but we would not disclose anything that could be used to identify those individuals. Finally, we never use or share the personally identifiable information provided to us online in ways unrelated to the ones described above without also providing you an opportunity to opt-out or otherwise prohibit such unrelated uses.

Our Commitment to Data Security

To prevent unauthorized access, maintain data accuracy, and ensure the correct use of information, we have put in place appropriate physical, electronic, and managerial procedures to safeguard and secure the information we collect online.





Our Commitment to Children's Privacy:

Protecting the privacy of the very young is especially important. For that reason, we never collect or maintain information at our websites from those we actually know are under the age of 18, and no part of our websites are structured to attract anyone under 18 years of age.

How You Can Access or Correct Your Information

You can access all your personally identifiable information that we collect online and maintain by contacting a customer service representative at 1-800-PRO-DEAL or email us at customerservice@prodealerbuttons.com. We use this procedure to better safeguard your information.

You can correct factual errors in your personally identifiable information by sending us a request that credibly shows error.

To protect your privacy and security, we will also take reasonable steps to verify your identity before granting access or making corrections.

How to Contact Us

Should you have other questions or concerns about these privacy policies, please call us at 1-800-PRO-DEAL or send us an email at customerservice@prodealerbuttons.com.

Warranty and Returns

For all returns, please e-mail our return service department. A customer service representative will e-mail you a Return Authorization Number (RA #). Upon receipt of the return, we will immediately ship out a replacement to you. The ProDealer Buttons comes with a 90 Day Warranty against manufacturer defects or malfunctions.

Steps to have your button replaced or serviced:

1. From an internet enabled computer please log onto www.ProDealerButtons.com
2. Please click on the link Support
3. Request a Return Authorization #
4. Fill out the Service Return Information
 - a. Your Name
 - b. Address
 - c. City
 - d. State
 - e. Zip Code
 - f. Country
 - g. Telephone Number
 - h. E-Mail Address





- i. Serial Number
- j. Receipt Information

5. Package the unit securely in bubble wrap and place it into a box that can be mailed

For all WARRANTY Returns

Please be sure to include:

- All Dealer Buttons & original packaging if within 90 Day Warranty (both must be in new condition)
- Return address
- Description of problem
- Legible copy of Original receipt

All NON-WARRANTY Returns

Contact a customer service representative for options.

SHIP ALL RETURNS TO:

(Please write RA# on the outside mailing envelope)

ProDealer Buttons – RA# (your assigned number)

4760 Preston Road, Suite 244 #195

Frisco, Texas 75034

FCC Statements of Compliance

Class B Digital Device Statement

FCC NOTICE (FCC ID: WEQ-PDB)

This product has been tested and complies with the specifications for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television

4760 Preston Road, Suite 244 #195

T: 214-227-9811

Frisco, TX 75034

F: 214-245-5442

tdpro.com





reception, which is found by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and devices
- Contact support@prodealerbuttons.com for assistance

Product:

ProDealer Buttons

FCC ID: WEQ-PDB

Table 1, FCC Statements of Compliance

Chapter

Table 1, Declaration of Conformity

FCC NOTICE (FCC ID: WEQ-PDB)

This device complies with the rules set forth in Part 15 by the Federal Communications Commission.

Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by TDPRO, LLC could void the user's authority to operate the equipment.

Responsible Party:

TDPRO, LLC

4760 Preston Road, Suite 244 #195

Frisco, Texas 75034

Phone: (214) 277-9811

Product:

ProDealer Buttons

FCC ID: WEQ-PDB

Table 2, Declaration of Conformity

Radiation Exposure Statement

FCC NOTICE (FCC ID: WEQ-PDB)

The antennas used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Product:

ProDealer Buttons

FCC ID: WEQ-PDB

Table 3, Radiation Exposure Statement





Modifications

FCC NOTICE (FCC ID: WEQ-PDB)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Product:

ProDealer Buttons

FCC ID: WEQ-PDB



4760 Preston Road, Suite 244 #195

T: 214-227-9811

tdpro.com

Frisco, TX 75034

F: 214-245-5442

