



Bluetooth Wireless Headset

User Manual Model : LORO WAVE



Thank you for purchasing the LORO WAVE Bluetooth Headset. We hope you enjoy it! This instruction manual will get you started and ready to make the most of your headset.


Contents

About your LORO WAVE.....	2
What's in your box	2
Headset composition.....	3
Specification.....	4
Charge your headset.....	5
Turn on/off your headset.....	5
Pair it with your phone	6



Figures / What the lights mean	7
--------------------------------------	---

Pair it with your Audio Gateway (Dongle)	8
--	---



How to.....

Make a call	9
Answer a call/ End a call	9
Reject a call / Volume control	10
Troubleshooting & FAQ	11
Taking care of your headset	12
Warranty	12,13

! Remember, driving comes first, not the call !

Using a mobile phone while driving can distract you and increase the likelihood of an accident. If driving conditions demand it (such as bad weather, high traffic density, presence of children in the car, difficult road conditions), pull off the road and park before making or answering calls. Also, try to keep conversations short and do not make notes or Read documents.


About your LORO WAVE headset.....

LORO WAVE What's in your box?



2

LORO WAVE Headset composition



- 1 LED Light
- 2 Charging socket
- 3 Microphone
- 4 Power button (Answer/end, On/Off)
- 5 Volume up(+), volume down(-)
- 6 Speaker

3

LORO WAVE Specification

Bluetooth Spec.	Version 2.0
Bluetooth Profiles	Bluetooth Headset Bluetooth Hands-free
Frequency	2.402 GHz ~ 2.480GHz
Operating Range	Up to 10m
Temperature of use	-20 ~ 55 °C
Dimension	18(W) * 60(L) * 8(D)mm
Weight	9g
Stand by time	Up to 100 hours
Talk time	Up to 5 hours
Battery charging time	Approx. 2.5 hours
Battery type	3.7v/100mA Li-ion Polymer

☞ Talk time & stand by time can be reduced due to environmental circumstances.

LORO WAVE Headset charging

Your LORO WAVE comes with a built-in rechargeable battery. Please make sure that your headset is fully charged before you start using it. Please allow at least approx. 2 ~ 3 hours for the first time charging.

- + Use the AC adaptor to charge from a power socket or USB charging cable.
- + When your headset is charging, the LED light on your headset shows steady red light.
- + When your headset battery is fully charged, the red LED light will go off

Turn your headset ON/OFF

- + Turn on
Press and hold the answer/end button for about 6 seconds, when red LED light flashes, your headset is on.
- + Turn off
Press and hold the answer/end button for about 5 seconds, when red LED light flashes, your headset is off.

☞ When your headset battery is low, the LED light will flashes RED every 2 ~ 3 seconds.



LORO WAVE.....Pair it with your phone

☞ Before you use your LORO WAVE headset, you need to pair it with your mobile phone.

- 1 – Press and hold answer/end button on your headset for about 9 seconds, when the LED light flashes Blue & Red alternately, your headset is locating any Bluetooth devices around it. In this case your mobile phone.
- 2 – Please refer to your Bluetooth mobile phone manual for registration about Bluetooth device with your phone. i.e. hands-free/headset.
- 3 – When your headset is located and register into your phone, your phone display will show the headset name “ LORO WAVE”
- 4 – In order to complete the registration process, please enter the pass code “ 0000 “ into your mobile phone using your phone keypad. Your phone will confirm when paring is complete. In case of unsuccessful pairing, please repeat steps 1 ~ 4 .

When you completed paring, LED light flashes Blue for every 5 Seconds for three times.

LORO WAVE.....Figures



What the lights mean

- ① Flashing Blue light.....Flashing 3 times: Stand-by mode
- ② Flashing Blue light.....Flashing every 5 seconds: active on call
- ③ Solid Red light..... Charging
- ④ Solid Red light off.....Fully charged
- ⑤ Flashing Blue/Red alternately.....In pairing mode

LORO WAVE & LORO Dongle (Audio gateway) pairing. (Option)

☞ For non-Bluetooth mobile phone, you may use your headset with Dongle by pairing , following steps.

- 1 – Press and hold answer/end button on your headset for about 9 seconds, when the LED light flashes Blue & Red alternately, your headset is location any Bluetooth devices around it. In this case your Dongle (Audio gateway).
- 2 – Please make sure your dongle is OFF, press and hold the power button for about 5 seconds until LED light flashes Blue and RED alternately. Now your headset & Dongle are locating each others. Release the power button, once they located, pairing will be completed automatically. For more detail, please refer to your Dongle user manual.

When you complete pairing, LED light for dongle flashes Blue for every 5 seconds.

! Every Audio gateway (Dongle) products' specifications & pairing steps may vary. Please refer to your Dongle user guide for more detail information.

LORO WAVE..... Make a call

1. **Tap** the answer/end button on your headset to display last called number on your mobile phone.
2. Once you found specific number, **tap** the answer/end button again to make a call.
(Dependent on your phone supporting this feature)
3. When you make a call from your mobile phone using keypad and **tap** the answer/end button on your headset.
(Subject to your phone setting)

LORO WAVE Answer a call / End a call

Answer a call

Tap the answer/end button on your headset to answer a call
(While your are wearing your headset, you can hear ring tone thru your headset when you receive a call. Dependent on your phone supporting this feature.)

End a call

Tap the answer/end button on your headset to end an active call.

LORO WAVE...Reject a call

.....

*** Dependent on your phone supporting this feature

Press the answer/end button when the phone rings to reject an incoming call. Depending on your phone settings, the person who called you will either be forwarded to your voice mail or hear a busy signal.

LORO WAVE....Adjust sound and volume

.....

Press the volume up or down (+ or -) to adjust the volume. You will not hear any beeping sound while you are adjusting the volume. Once you reach maximum or minimum volume then you will hear long beeping sound.

LORO WAVE....it is easy to operate

.....

The LORO WAVE is easy to operate. The answer/end button on the headset performs different functions depending on how long you press it.

Instruction:

Tap
Press
Press and hold

Duration of press:

Press briefly
Approx: 1 second
Approx: 5 seconds

Troubleshooting & FAQ

.....

I hear crackling noises

For the best audio quality, always wear your headset on the same side of the body as your mobile phone.

I cannot hear anything in my headset

- * Increase the volume on the headset
- * Ensure that the headset is paired with the phone
- * Make sure that the phone is connected to the headset—if it does not connect either from the phone's Bluetooth menu or by tapping the answer/end button, follow the pairing procedure.

I have trouble pairing LORO WAVE with my phone

1. You may have deleted your headset pairing in your mobile phone. Follow the pairing procedure.
2. You can pair your LORO WAVE with different phones or Bluetooth devices. If your headset is connected to another phone or other Bluetooth devices, disconnect the LORO WAVE from the previously used phone using the phone set up menu.
3. There is also the possibility that the LORO WAVE is searching for a device to connect to. Wait about 30 seconds and try again.
4. Check the phone screen to ensure that the LORO WAVE is not awaiting a response from your mobile phone set up menu.

I cannot use Reject call, Call on hold, Redial or Voice dialing

These functions are dependent on your phone supporting them. please check your phone's manual for further details.

LORO WAVE....Taking care of your headset

For optimal performance, wear the LORO WAVE and your mobile phone on the same side of your body or within line of sight. In general, you will get better performance when there are no obstructions between your headset and your mobile phone.

1. Always store the LORO WAVE with power off and safely protected.
2. Avoid storage at high temperatures (above 60 deg.C/134 deg.F) –such as in a hot vehicle or in direct sunlight. (Storage at high temperatures can degrade performance and reduce battery life.)
3. Do not expose the headset or any of its supplied parts to rain or other liquids.


Warranty

BOYOUNG TECH TECHNOLOGY & MARKETING, Inc. warrants this product against all

Defects in material and workmanship for a period of one year from the Date of original purchase. The conditions of this warranty and our Responsibilities under this warranty are as follows:

- The warranty is limited to the original purchase.
- A copy of your receipt or other proof of purchase is required.
- The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation, modification, or repair by unauthorized third parties.
- The responsibility of BOYOUNG TECH TECHNOLOGY & MARKETING, Inc. products shall be limited to the repair or replacement of the product as its sole discretion.

- Any implied warranty on BOYOUNG TECH TECHNOLOGY & MARKETING, Inc. products is limited to one year from the date of purchase on all parts, including any cords and connectors.
- Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear, such as microphone windscreens, ear cushions, decorative finishes, batteries, and other accessories.
- BOYOUNG TECH TECHNOLOGY & MARKETING, Inc. is not liable for any incidental or consequential damages arising from the use or misuse of any BOYOUNG TECH TECHNOLOGY & MARKETING, Inc. product.
- This warranty gives you specific rights and you may have other rights which vary from area to area.
- Unless otherwise instructed in the Use Manual, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on this unit, whether in or out of warranty. It must be returned to the purchase point, factory or authorized service agency for all such work.
- BOYOUNG TECH TECHNOLOGY & MARKETING, Inc. will not assume any responsibility for any loss or damage incurred in shipping. Any repair work on BOYOUNG TECH TECHNOLOGY & MARKETING, Inc. products by unauthorized third parties voids any warranty.



FCC (Federal Communications Commission)

WARNING: This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

This device complies with Part 15 of the FCC's Rules. Operation is subject to the following two Conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesirable operation.

Hereby, BOYOUNG TECH TECHNOLOGY & MARKETING, Inc. declares that this LORO WAVE is in compliance with the essential requirements and other relevant provisions of directive 1999/5/EC.



Bluetooth Wireless Headset

! Remember, driving comes first,
not the call !



서울시 영등포구 문래동3가 84-2 동국메뜨리앙 602

TEL/ 02-566-7316~7 FAX/ 02-2636-7328

<http://www.myloro.com>