

Simplified Operation Guide for HMC-3911

1. Main Features

- ★ Recording
- ★ Multimedia Playback (Movies, Music, Photos)
- ★ Network Media Streaming
- ★ Removable Storage

2. Power on/off

When the power cord is connected to the DC-IN jack of the unit, it will enter the standby mode soon, and the **STANDBY** LED on the front panel will turn on. Then you can press the **POWER** button on the front panel or remote control to turn on the unit.

3. How to get output on a TV set?

The unit supports three video output mode: Composite, Component, and HDMI.

Composite: Connect one end of the audio visual cable to the A/V OUT jack on the rear panel of the unit, connect the other end to the A/V IN jack of the TV set;

Component: Use the Y/Pb/Pr cable to connect the Y/Pb/Pr jacks on the unit and the TV set;

HDMI: Use the HDMI cable to connect the HDMI jacks on the unit and the TV set.

All video output are of auto detection. You can press the **TV SYSTEM** button on the remote control to adjust screen resolution.

4. Recording a TV program

(1) Connection

Connect the source from a Set-Top Box or DVD player etc. via an audio visual cable to the A/V IN jack on the rear panel of the unit.

(2) Recording

Press the **REC** button on the remote control to start recording;

Press the **STOP** button on the remote control to stop recording.

Recorded titles can be seen and edited in the **Playback** menu. When the highlight is moved onto a title, you can press the **PLAY** or **ENTER** button to view the title, and press the **RETURN** or **STOP** button to stop playback.

5. Browsing multimedia content stored on USB, HDD, or NET

User can browse movies, music and photos in the **Browser** menu.

(1) Selecting Filter

While in the **Browser** menu, you can press the **LEFT/RIGHT** button to select content filter 'All',

'Music', 'Photos', 'Movies'.

(2) Selecting Device

Press the **UP/DOWN** button to select between **USB**, **HDD**, and **NET**.

USB – USB mass storage devices such as USB stick, external USB HDD, etc. connected to the USB HOST ports.

HDD - The internal SATA HDD.

NET – Local Area Network, you need to connect the unit to a LAN via Ethernet cable first.

(3) Playback

Use the navigational buttons to locate the media file you wish to browse in the device. Then press the **PLAY** or **ENTER** button to view the file, and press the **RETURN** or **STOP** button to stop playback.

6. Connection to computer

While the player is powered on, connect the mini connector on the USB cable to the **USB DEVICE** jack on the rear panel of the unit. Connect the other connector to the computer's USB port. Then you can use the unit as a removable storage device.