

Operator's manual

LED Gas price changer



MCLICKPLUS CO. LTD.

#512 World Meridian Venture Center 2, 426-5 Gasan-dong, Geumcheon-gu, Seoul, Korea
Tel . 82-2-3466-9900, Fax . 82-2-3466-9955

Contents

1. Introduction.....	3
2. Console.....	4
3. LED Displayer.....	5
4. Console Settings.....	6
5. Select display line.....	7
6. Price Display Window.....	8
7. Price Change.....	8
8. LED Display Board Setting.....	9
9. Settings for installing multiple sets.....	10

1. Introduction

The LED Gas Price Changer is very convenient product that Gas price can be very easy changed from an indoor or outdoor location using the wireless terminal at office. This gives you easy to work as well as eliminating the need to manually change plastic signs

Features

Power (Operating Voltage):	120 V AC / 240V AC Available
Operating Temperature	: -40° to 120° F / -40° to 50° C
Character Heights	: Choose from a large Range of character heights 8" to 48"
Full Numeric Values	: 3 digit number with a decimal point and a fraction
LED Viewing Angle	: 90° and 140°
Communication	: Wireless terminal - up to 1 Km (line of sight) Frequency Bandwidth - 433.92MHz Modulation – FSK Baud rate – 1200 BPS
LED Color	: Red, Green, Amber (Option)
Warranty	: 1 Year

Note

Communication Protocol between Console and Displayer

STF 1byte 0x7e

Id 1byte 0xid

Data length 1byte 0xnn

Data nn byte 0xXX,0xXX,,


Crc 1byte 0xXX.

EDF 1byte 0xe7

* FCC Manual Information requirement


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2. Console




Power adapter

3. LED Displayer




4. Console Settings




Family Address Switch choose one from 0 ~ F.
Choose one from "Zero" to "F".
Both Console and LED displays should use
the same address.

5. Select display line


“1” is ‘on’ for Regular line “on”




“1” and “2” are ‘on’
for Regular / Super lines “on”




“1” and “2”, “3” are ‘on’
for Regular / Super/
Premium lines “on”



“1” and “2”, “3”, “4” are ‘on’
for Regular / Super/
Premium / Diesel lines “on”



6. Price Display Window



7. Price Change



“Red” position disables any key input.

Each price can be changed using the keys on a same line.

- ① Select a digit using “◀” Key
- ② Increment a digit number using “▲” key
- ③ Decrement a digit number using “▼” key

Whenever push a keypad, beep sounds.

After setting Prices, use “SEND” key to change the price on the LED displays.


8. LED Display Board Setting

LED brightness selection

Brightness	"A" DIP Switch
1	1 2 3 4
Auto	Off X X X
Manual	On X X X
07 (Lower)	X On On On
06	X Off On On
05	X On Off On
04	X Off Off On
03	X On On Off
02	X Off On Off
01	X On Off Off
0(Higher)	X Off Off Off

Gas Grade Selection

Sort of Gas	1	2	3	4	"B" DIP Switch
Regular	On	Off	Off	Off	
Super	Off	On	Off	Off	
Premium	Off	Off	On	Off	
Diesel	Off	Off	Off	On	



9. Settings for installing multiple sets

In case of installing multiple LED display boards within a Gas station, LED displayers for the same sort of Gas have the same address.

