



Multi-Web PAD

Users Manual



www.e-detail.co.kr

Multi-Web PAD

Users Manual

Copyright

- All rights of this manual belongs to Maxuracy Co., Ltd, and it is prohibited to use or copy all or part of this manual without any prior approval by this company.
- Details of this manual is changeable according to purchased Multi-Web Pad models, and can be adjusted without any previous notice in cases of functions-improvement etc.
- This company does not take responsibilities for any damage occurred due to using any product out of designated standards or because users did not follow the attentions and directions on the manual about how to use, We ask you to use it very carefully.


Multi-Web PAD

A Table of Content

<u>1 Constituent Units</u>	2
<u>2 Before Use</u>	3
2-1 Introduction	3
2-2 Attentions for Use	4
2-3 Correct Attitudes to Use	21
<u>3 Merits of the Product</u>	23
<u>4 Names of Each Part</u>	25
<u>5 How to Use Multi-Web PAD</u>	31
5-1 Stylus Pen	33
5-2 Putting-in Letters	37
5-3 Using Buttons	38
<u>6 Window Screen Composition</u>	48
<u>7 Using Internet</u>	62
<u>8 Establishment of Screen Brightness</u>	66
<u>9 Setup</u>	67
<u>10 Using Batteries</u>	70
<u>11 Preventing Robbery</u>	73
<u>12 Specifications of the Product</u>	74
<u>13 Warrantee Letter and Customers Support</u>	75

Multi-Web PAD


Constituent Units




Body



Users Manual



12V Adapter



Pouch



AC Cord

Multi-Web PAD

● Before Reading the Manual

► Introduction of the Manual

- This is a manual offered with the product for users conveniently see when they purchase and use this product for the first time.
- Multi-Web PAD can be more convenient and easy when you properly use this manual at each case.

► Content of the Manual

- Merits and constituent units of Multi-Web PAD are explained.
- Basic usage of Multi-Web PAD is explained.
- Functions of Multi-Web PAD and how to use them are explained.

► How to Utilize the Manual

- Please read attentions for safety without fail, before using Multi-Web PAD.
- Refer to the manual to find out how to use Multi-Web PAD.
- You can easily look for required information by using an index.
- You can easily understand a difficult term if any, by using explanations on the manual.
- Utilize Q&A of the manual if you face any problem.



Reference

- Some devices and soft wares among body text of the manual may not be available or different due to such reasons as version change. Please understand that users' Multi-Web PAD environment may not conform to the manual.
- Pictures in the body text and cover of the manual may be different from actual images. This manual explains about how to operate it by Stylus pen or by mouse. 'Click' on the manual is same with 'One touch' by Stylus pen.
- Drawings on the manual is explained by the standard of Window XP Tablet PC Edition. Drawings in the manual are changeable.
- of provided manual may be partially different according to models.

Multi-Web PAD

● Directions for Safe Use

Please read the 'attentions' without fail before using the product, for safe and correct use of the product. That is to prevent any damage in property or body wound due to unpredicted danger.

Division and Content of Attention Marks

	Warning	The user may be badly wounded or dead if he does not follow the instructions.
	Attention!	The user may be wound or it may cause loss in property if he does not follow the instructions.
	Attention!	The product may be damaged in case of not following the instructions.
	Reference	It offers information to help users in the middle of using the product.

● FCC Manual Information

requirement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Multi-Web PAD

Attentions related with Installation

⚠ Warning

These are the cases where the user may be badly wounded or dead if he does not follow the instructions.




Install it in sufficiently wide space (at more than 10cm distance between Multi-Web PAD and the wall) where is well ventilated. Be careful not to block an opening.

※In case a fire breaks out or if the product contacts with the wall, users may get burned since inner temperature goes up.



Keep this product from wet places such as bathroom.

※The product may be damaged or users may be suffer from electric shock.



Do not install or use on tilted or shaking area but on horizontal site.

※The product may malfunction or be damaged.



Dispose packing paper or desiccants out of children's reach.

※In case a user swallowed the desiccant, let him immediately vomit it and take him to the hospital as soon as possible. You could be suffocated if you wear the packing vinyl.



Do not recklessly neglect power and LAN cables as they are.

※You may tumble down when you pass by, which could lead to electric shock, fire, and product damage or body wound.

Multi-Web PAD

Do not install the product around an aquarium, a humidifier, or heat-products such as stove.

※It could bring danger of over-heat, electric shock or fire.

Do not install the product around any electric appliances with much electric waves.

※It could bring danger of system damage or electric shock.

⚠ Attention!

These are the cases where the user may be wounded or it may cause loss in property unless he follows the instructions.



Do not install the product where the product may fall down easily.

※It could lead to product damage or body wound if the product falls down.



Keep this product out of direct rays of the sun.

※It could lead system damage or electric shock.



Keep this product from magnetic things but install on the clean area.

※The product may malfunction or be damaged.

Multi-Web PAD

Attention Related with Power



Warning


These are the cases where the user may be badly wounded or dead if he does not follow the instructions.

Connect the power cable with a consent or multi consent on a ground terminal.

※Unless it may lead to electric leakage or electric shock.

Use the rated voltage, and correctly plug the power cable into the consent and adapter.

※Unless it could lead to product damage, electric shock, or fire.
(The consent image may be different according to specification of each nation or product.)



Do not use damaged or loosen cable or consent.

※Unless it could incur electric shock or fire.



Do not pull out the power cable but disconnect it while holding it.

※Cable damage may lead to electric shock or fire.

Do not excessively crook the power cable, and do not put any heavy or humid thing on the product.

※Cable damage may lead to electric shock or fire.


Multi-Web PAD

Keep any kids or pets from approaching or damaging a plug, or power cable.

※Damaged cable or plug may lead to electric shock or fire.

Disconnect the power cable from the consent if there comes any strange smell or noise.

※There is danger of fire and electric shock.



Do not suit yourself by disassembling or assembling power-supplier or adapter.

※There is danger of electric shock.



Keep any wet hand from power cable and plug. Firstly dry any wet or dusty plug pins without fail, before using.

※There is danger of fire and electric shock.

Do not use other electric appliances or electric heater with this product at the same time.

※It may be over-heated which could lead to fire or product damage.


In case of any thunder or lightening, disconnect the power cable and modem cable from the product.

※There is danger of electric shock.

Multi-Web PAD

Disconnect the power cable from the plug if you don't use the product for a long time. Manage the product not to wear any dust or foreign things.

※There is danger of fire.



Do not put any fork, chopsticks, or any conductor in one groove of the power cable in state of connecting the cable in the plug.

※There is danger of electric shock.

Disconnect the power cable from AC adapter if there comes any strange noise or smell, or if it is over-heated.

※There is danger of electric shock or fire.



Attention!

These are the cases where the user may be wounded or it could incur any loss in property if he does not follow the instructions.

Do not plug out or disconnect the power cable in the middle of using the product.

※The product may be damaged due to electric shock.

Do not plug out or disconnect the power cable when the product is being operated only by AC adapter with no batteries.

※The product may be damaged due to electric shock.

Multi-Web PAD



Warning

These are the cases where the user may be badly wounded or dead if he does not follow the instructions.



Keep water and other foreign things from inside of the power input jack, adapter or Multi-Web PAD. In case any water or foreign things were flowed in, disconnect the power cable (disconnect the battery if that offers power) and contact the service center.

※If the inner parts of the Multi-Web PAD get damaged, it could lead to fire or electric shock.

Keep any cup with water, beverage, or medicine from around the Multi-Web PAD.

※There is danger of fire or electric shock if any liquid flowed in the product.



Plug out the power cable and take safety test from the service center if you fell down Multi-Web PAD or it was damaged.

※There is danger of fire or electric shock in case of using any damaged product.

Be careful not to expose the product in direct rays of the sun, especially in hermetically sealed spaces such as in a car.

※product may be deformed due to raised temperature, and there is danger of fire.

Firstly terminate the system and then the connected cable when you disassemble Multi-Web PAD. In case there is a modem, disconnect the telephone cable and then disassemble the battery of Multi-Web PAD essentially.

※There is danger of electric shock.

Multi-Web PAD



Attention!

These are the cases where the user may be wounded or it could incur any loss in property unless he follows the instructions.

Do not put any inflammable or weighty things on the product.

※There is danger of fire or electric shock, and the user may hurt it the thing on the product fell down.

Use approved products only in case of connecting others with the connector or port of Multi-Web PAD.

※Unapproved products may incur any fire or electric shock.

Be careful not to drop Multi-Web PAD.

※The user may get wounded, and the product or battery may be damaged.

Please read the manual annexed with the newly purchased good without fail and follow it when you manage parts of Multi-Web PAD.

※Product damage is worried.

Do not knock or scratch TFT LCD with sharp or pointed tip of things.

※TFT LCD may be damaged.

Multi-Web PAD

Scrub TFT LCD with soft and dry fabric. Do not use any wet fabric or chemicals then.

※TFT LCD may be deformed.

When you clean Multi-Web PAD, slightly scrub it with soft and dry fabric after applying proper amount of computer cleanser. Use the product after perfectly drying it.

※There is danger of fire or electric shock if you use the product in wet state.

Bad Resolution of TFT LCD

※There may be less than 4 bad resolutions due to technical limitation of LCD manufacturing process. Less than 4 bad resolutions do not influence on function and performance of Multi-Web PAD, while other companies may have the same level of bad resolutions.

Multi-Web PAD



Warning

These are the cases where the user may be badly wounded or dead if he does not follow the instructions.

Follow the instructions of pertinent organizations to use wireless LAN in where it is banned, (e.g.: airplane, train, hospital etc.)

※Unpredicted accident may happen.

Firstly power off without fail and disconnect all the cables before making a move.

※There is danger of product damage or electric shock.



Be careful not to shock the product while making a move.

※There is danger of product damage or user's wound.

Please fold TFT LCD on the back of Multi-Web PAD essentially while you are moving.

※Unless there may be damage in the product or TFT LCD.

Do not operate Multi-Web PAD while you are driving.

※It becomes a cause of traffic accident.

Multi-Web PAD



Please keep the Stylus pen out of kids' reach.

※The kid may eat it, be pricked by it, or get hurt.



Attention!

These are the cases where the user may be wounded or it may cause loss in property unless he follows the instructions.

Please store it at a proper temperature,
(temperature for storage: 0~50°C, humidity for storage: 5~90%).

※Unless it may be a cause of damaged product.

Pull the battery out of Multi-Web PAD to store it for a long time.

※There is danger of damage in product or battery.

Multi-Web PAD



Attention!

These are the cases where the user may be wounded or it may cause loss in property unless he follows the instructions.

When you disassembled and reformed Multi-Web PAD at your liberty, you must pay despite it is guaranteed period.

※Do not disassemble Multi-Web PAD since it is consisted of many pieces of minute parts. Please contact the service center if there is any abnormality in the product.



Do not disassemble with wet hands.
※There is danger of electric shock.

You must not disassemble but use only designated devices, (USB and battery.)

※There is danger of product damage, electric shock, or fire.

Do not use any magnetic tool.

※It may cause damage in the system drive or other parts due to electric characters of parts in the product.

Multi-Web PAD

Attentions related with Battery



Warning

These are the cases where the user may be badly wounded or dead unless he follows the instructions.

Use Multi-Web-PAD-exclusive battery only.

※There is danger of electric shock or fire if you use other batteries than what are supplied when you purchased the goods.

Do not mouth the battery. (Especially watch out kids or pets not to mouth it.)

※There is danger of product damage or electric shock.

Do not use the battery where is overheated and do not leave it where is exposed to much direct rays of the sun.

※There is danger of explosion or fire.

Do not disassemble or shock the battery, and be careful not to drop it in the water.

※There is danger of explosion or fire.

Keep any metal things such as car keys or clips from touching the battery.

※There is danger of battery damage or fire due to excessive electric wave.