

User Manual

YK110-4X-FCC Remote Control

1. Specification:

Operational frequency: 315.0775MHz

Modulation type: OOK

RF power: 1mW

Rated Voltage: DC 12V (27A/12V Battery)

Rated current: <13mA

2. How to use this remote control

Press the button D0 of the remote control, then the LED indicator is light, at the same time to transmitting data signal D0. Release the button, remote control to stop transmitting and LED indicator off.

Press the button D1 of the remote control, then the LED indicator is light, at the same time to transmitting data signal D1. Release the button, remote control to stop transmitting and LED indicator off.

Press the button D2 of the remote control, then the LED indicator is light, at the same time to transmitting data signal D2. Release the button, remote control to stop transmitting and LED indicator off.

Press the button D3 of the remote control, then the LED indicator is light, at the same time to transmitting data signal D3. Release the button, remote control to stop transmitting and LED indicator off.

3. Notes

If the transmit range near or the LED indicator dim, please replace the battery.

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for and radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.